



# ALPHA X SERIES TOTAL STATION

## Instruction Manual



GUANGZHOU ALPHA GEO-INFO CO.LTD

## **Foreword**

Thanks for purchasing the ALPHA X series total station. In order to use the instrument well, please read this instruction manual carefully and keep it cautiously for consulting in the further.

## **Product confirmation:**

Please fill the model and the serial number of your instrument in corresponding blank. Feedback to local distributor or our sales department.

**NOTE :**

- Please read this instruction manual carefully before use it.
- Avoiding insulates the instrument, and don't collimate the sun directly for protecting eyes and instrument.
- When using it please insure the connection between tripod and instrument is firm. If raining, you can hood it with rainproof cover.
- Please loose the clamp system when the instrument in the case, and keep the case dry.
- When transporting, keep the instrument in the case and try your best to lighten librations.
- After working in wet or raining condition, please wipe water on surface and keep it in air, when it is dry completely, you can put it in the case.
- Don't clean the instrument surface with alcohol, aether or other irritant chemical things; and use the equipped paper to clean the optical parts.
- If you do not use the instrument for a long time, you should take the battery pack down and recharge once every month.
- If you do not use the instrument for a long time, take the instrument out of the case and keep it in the dry condition.
- If the temperature changing is sharp (for example: move it out from one hot vehicle), the measured data will be influenced, so it can be used when it adapts the surrounding condition.
- Before use it, you should check the voltage for whether it is enough.
- Do not remove the battery at working time, otherwise some settings or measured data may be lost.

## Safety Cautions:

- **There is a risk of fire, electric shock or physical harm if you attempt to disassemble or repair the instrument yourself.**

This is only to be carried out by ALPHAGEO or an authorized dealer, only!

- **Cause eye injury or blindness.**

Do not look at the sun through a telescope.

- **Laser beams can be dangerous, and can cause eye injury if used incorrectly.**

Never attempt to repair the instrument yourself.

- **Cause eye injury or blindness.**

Do not stare into laser beam.

- **High temperature may cause fire.**

Do not cover the charger while it is charging.

- **Risk of fire or electric shock.**

Do not use damaged power cable, plug and socket.

- **Risk of fire or electric shock.**

Do not use a wet battery or charger.

- **May ignite explosively.**

Never use an instrument near flammable gas, liquid matter, and do not use in a coal mine.

- **Battery can cause explosion or injury.**

Do not dispose in fire or heat.

- **Risk of fire or electric shock.**

Do not use any other type of charger other than the one specified.

- **Risk of fire.**

Do not use any other power cable other than the one specified.

- **The short circuit of a battery can cause a fire.**

## **CAUTION!**

- Do not connect or disconnect equipment with wet hands, you are at risk of electric shocks if you do!

- Risk of injury by overturn the carrying case.

Do not stand or sit on the carrying cases.

- Please note that the tips of tripod can be hazardous, be aware of this when setting up or carrying the tripod.

- Risk of injury by falling down the instrument or case.

Do not use a carrying case with a damaged which belts, grips or latches.

- Do not allow skin or clothing to come into contact with acid from the batteries, if this does occur then wash off with copious amounts of water and seek medical advice.

- Ensure that you mount the Tribrach correctly, failing to do so may result in injury if the tribrach were to fall over.

- It could be dangerous if the instrument falls over, please check that you fix the instrument to the tripod correctly.

- Risk of injury by falling down a tripod and an instrument.

Always check that the screws of tripod are tightened.

- It could cause measurement error when there is leave or other object between instrument and target.

## **User**

1. This product is for professional use only!

The user is required to be a qualified surveyor or have a good knowledge of surveying, in order to understand the user manual and safety instructions, before operating, inspecting or adjusting.

2. Wear the required protectors (safety shoes, helmet, etc.) when operating.

## **Exceptions from Responsibility**

- 1) The user of these products is expected to follow all operating instructions and make periodic checks of the product's performance.
- 2) The manufacturer, assumes no responsibility for results of a faulty or intentional usage or misuse including any direct, indirect, consequential damage, and loss of profits.
- 3) The manufacturer assumes no responsibility for consequential damage, and loss of profits by any disaster, (an earthquake, storms, floods etc.).
- 4) The manufacturer assumes no responsibility for any damage, and loss of profits due to a change of data, loss of data, an interruption of business etc., caused by using the product or an unusable product.
- 5) The manufacturer assumes no responsibility for any damage, and loss of profits caused by usage except for explained in the user manual.
- 6) The manufacturer assumes no responsibility for damage caused by wrong transport, or action due to connecting with other products.

## **Safety Standards for ALPHA X EDM Laser (ALPHA X series)**

ALPHA X series adopt the class of Laser Product according to IEC Standard Publication 60825-1 Amd. 2:2001. According this standard, EDM device is classified as Class 3R Laser Product when reflectorless measurement is selected, when the prism and reflective sheet is selected as target, the output is equivalent to the safer class 1. Follow the safety instructions on the labels to ensure safe use.

CAUTION: CLASS 3R LASER RADIATION WHEN OPEN

AVOID DIRECT EYE EXPOSURE.

CAUTION: CLASS 1 LASER RADIATIONS WHEN OPEN


DO NOT STARE INTO THE BEAM

## Note for Safety



### WARNING

- Never point the laser beam at other's eyes, it could cause serious injury.
- Never look directly into the laser beam source, it could cause permanent eye damage.
- Never stare at the laser beam, it could cause permanent eye damage.
- Never look at the laser beam through a telescope or other optical devices, it could cause permanent eye damage.



## Content

Applications .....	1
1. Nomenclature and functions.....	2
1.1 Nomenclature .....	2
1.2 Display.....	3
1.3 Operating Key .....	5
1.4 Function key (Soft Key).....	6
2. Battery .....	8
2.1 Mounting the battery .....	8
2.2 Recharge.....	9
3. Preparation for measurement .....	10
3.1 Setting up the instrument.....	10
3.2 Leveling the instrument.....	10
3.3 Centering .....	12
3.3.1 Centering with optical plummet.....	12
3.3.2 Centering with laser plummet.....	12
3.4 Focusing .....	13
3.5 Switch on.....	13
3.6 Switch off .....	14
3.7 The function of ★ key menu.....	14
3.8 How to input number and letter.....	15
3.9 Vertical Angle Tilt Correction .....	16
4. Angle Measurement .....	17
4.1 Measuring Horizontal Angle (Right) and Vertical Angle ..	17
4.2 Switching Horizontal Angle Right/ Left .....	18
4.3 Set a Horizontal Angle.....	19
4.4 Vertical Angle Grade Mode Switch .....	21
4.5 Zenith distance/ vertical angle mode switch .....	21
4.6 Set Buzzer Sounding for Horizontal Angle 90° .....	22
5. Distance Measurement.....	23



5.1 Distance Measurement (Slope distance mode).....	23
5.2 Stake out (S.O).....	24
5.3 Set distance measurement mode .....	25
5.4 Set distance unit .....	26
5.5 Setting of the Atmospheric Correction.....	27
5.6 Returned signal Checking .....	28
5.7 Setting distance measurement times (Factory setting is “3”) .....	29
6. Coordinate Measurement.....	30
6.1 Setting Coordinate of Occupied point.....	31
6.2 Setting of instrument height .....	32
6.3 Setting of target height .....	33
6.4 Setting coordinate of backsight point.....	34
6.5 Measuring point coordinate.....	35
7. Data collection.....	36
7.1 Data collection menu operation .....	36
7.2 Selecting a file for data collection .....	37
7.3 Selecting a coordinate file for data collection .....	37
7.4 Occupied Point Setting.....	39
7.5 Backsight Point .....	42
7.6 Operational Procedure of “Data Collect” .....	44
7.7 Setting PCODE for measured point.....	46
7.7.1 Entering PCODE / ID using PCODE Library.....	46
7.7.2 Entering PCODE / ID from the list of PCODE.....	47
7.8 Data Collect Offset Measurement mode.....	48
7.8.1 Angle offset measurement .....	48
7.8.2 Distance Offset Measurement .....	50
7.8.3 Plane Offset Measurement .....	52
7.8.4 Column Offset Measurement .....	54
7.9 NEZ Auto Calculation.....	56

7.10 “Setting Parameter of Data Collect [CONFIG.]” .....	56
7.11 Setting Parameter of Data Collect [CONFIG.] .....	57
8. Coordinate Layout .....	59
8.1 Layout procedures .....	59
8.2 Selecting or creating a coordinate data file .....	59
8.3 Occupied Point Setting .....	61
8.4 Setting Backsight Point .....	63
8.5 Executing a Layout .....	64
8.6 Setting the GRID FACTOR .....	68
9. Application Measurement (Programs) .....	70
9.1 Remote Elevation Measurement (REM) .....	70
9.2 Missing Line Measurement (MLM) .....	73
9.2.1 Missing Line Measurement .....	73
9.2.2 USE FILE and GRID FACTOR .....	76
9.2.3 Use coordinate for MLM program .....	77
9.3 Setting Z Coordinate of Occupied Point .....	78
9.4 Area Measurement .....	82
9.4.1 Area Calculation from Coordinate Data File .....	82
9.4.2 Area Calculation from measured data .....	83
9.5 Point to Line .....	85
9.6 Setting a new point .....	88
9.6.1 Side short method .....	88
9.6.2 Resection method .....	90
9.7 Road measurement .....	93
9.7.1 Input Element .....	94
9.7.2 Road Setout .....	99
10. Memory Manager Mode .....	106
10.1 Enter Memory Manager Mode .....	106
10.2 Display Internal Memory Status .....	107
10.3 Searching data .....	107

10.3.1 Measured data searching .....	107
10.3.2 Coordinate Data Searching .....	109
10.3.3 PCODE Library Searching .....	110
10.4 File Maintenance .....	111
10.4.1 Rename a file.....	112
10.4.2 Deleting a File .....	112
10.4.3 Searching Data in a File .....	113
10.5 Coordinate Data Direct Key input .....	113
10.6 Delete a Coordinate Data from a File.....	115
10.7 Editing PCODE Library.....	116
10.8 Data Transfer by serial port .....	117
10.8.1 Sending data.....	117
10.8.2 Loading data.....	118
10.8.3 Setting parameter of data communications.....	119
10.9 Memory initialize .....	120
10.10 MEMORY SELECT.....	121
10.11 Connect PC via miniUSB port .....	122
10.12 DAT data change .....	123
11. Instrument Settings .....	124
11.1 Items of instrument settings.....	124
(* factory setting).....	125
11.2 Enter setting mode .....	126
11.3 Setting procedures .....	127
12. Selecting Mode .....	128
12.1 Items of selecting mode.....	128
12.2 How to set selecting mode .....	132
13. Check and adjustment .....	134
13.1 Checking and adjusting of instrument constant .....	134
13.2 Checking/adjusting the plate level.....	136
13.3 Checking/adjusting the circular level Check .....	137

13.4 Checking/adjusting the optical sight.....	138
13.5 Checking/Adjusting the plummet.....	139
13.5.1 Checking/Adjusting the optical plummet Check.	139
13.5.2 Checking/Adjusting the laser plummet (Optional accessory) .....	140
13.6 Checking/Adjusting the vertical cross-hair on telescope Adjustment.....	141
13.7 Checking/adjusting horizontal collimation error Check.	142
13.8 Checking/adjusting of the vertical index error i.....	142
13.9 Checking the optical axis.....	145
14. Packing list.....	146
Attachment 1: atmospheric correction formula and chart (for your reference).....	147
Attachment 2 Correction for refraction and earth curvature .....	150
Attached file 3: communication instruction and data format .....	151

## **Applications**

ALPHA X series Total Station applied absolute encoder system to digital angle measurements, it adopts phases measurement system to measure distance. It can measure distance not only with prism but also with reflective sheet, so much as it can work without cooperate objective. It can achieve measurement, calculating, display and storage etc. by means of microcomputer-technology. It can display measuring results of horizontal, vertical angle and distance at the same time.

These series Total Station is designed for engineering items, especially for every construction area. It can be used in coordinate measurement or location measurement for construction, remote elevation measurement, plumb line surveying, ductwork surveying and sectional surveying etc. It also can be used in triangulation control survey, cadastral surveying, topographic surveying and house property surveying.

# 1. Nomenclature and functions

## 1.1 Nomenclature




## 1.2 Display


The display uses self-luminous pattern LCD which has 6 lines and 8 characters per line. In general, the upper five lines display measured data, and the sixth line displays the soft key function which changes with the measuring mode.

There are two type modes: measurement mode and menu mode.


### ◆ Measurement mode of ALPHA X series:

VZ: 81° 54' 21"	
HR: 157° 33' 58"	
0SET HOLD HSET P1	

Angle measurement mode  
Zenith distance: 81° 54' 21"  
H-angle: 157° 33' 58"

HR: 157° 33' 58"	
VZ: 81° 54' 21"	
SD: 1.425m	
HD: 0.645m	
VD: 1.271m	
DIST MODE S/A P1	



Distance measurement mode 1  
Zenith distance: 81° 54' 21"  
H-angle: 157° 33' 58"  
Slope distance: 1.425 m  
Horizontal distance: 0.645 m  
Vertical distance: 1.271m

N: 5.868m	
E: -3.308m	
Z: 0.226m	
DIST MODE S/A P1	

Coordinate measurement mode

N: 5.868 m  
E: -3.308 m  
Z: 0.226 m

◆ Example of menu mode:



MENU(page 1,total 4)

PARAMETERS

Press F1 enter “data collect”

Press F1 enter “min.angle reading”

Press F2 enter “layout”

Press F2 enter “auto off”

Press F3 enter “memory MGR.”

Press F3 enter “tilt” for sensor

Press F4 enter “programs”

Press F4 enter “RS-232C”



◆ Display mark

VZ	Zenith distance
VH	Height angle
V%	grade
HR/HL	H-angle right/H-angle left
SD/HD/VD	S-distance/H-distance/Vertical distance
N	N coordinate
E	E coordinate
Z	Z coordinate
PT#	Point number
ST/BS/SS	Measured station/Backsight/Collected point
Ins.Hi(I.HT)	Instrument height
Ref.Hr(R.HT)	Prism height
ID	Registered number of PCODE
PCODE	Point code
1/3. 2/3. 3/3	Page 1/Page 2/Page 3



### 1.3 Operating Key



Keys	1st Function	2nd Function
F1-F4	Functions keys correspond message displayed	Functions keys correspond message displayed
0~9	Enter number	Enter letter or other character
ESC	Escape from menu	
★	Hot key for fast settings	
①	Power on/off	
MENU	Enter menu	
ANG	Switches to the angle measurement mode	
	Enter S-distance H-distance model measurement model	
	Enter coordinate measurement model	
ENT	Confirm data entry	

## 1.4 Function key (Soft Key)

The Soft Key function is displayed at the bottom line of display.

The function is changed with measurement mode.

VZ:	81°	54'	21"
HR:	157°	33'	58"
0SET HOLD HSET P1			

• • • •  
**F1 F2 F3 F4**

### Function key

VZ:	90°	16'	00"
HR:	156°	16'	18"
0SET HOLD HSET P1			
TILT	REMS	V%	P2
HABZ	HARL	CMPS	P3

Angle measurement mode

N:	5.868m
E:	-3.308m
Z:	0.226m
DIST MODE S/A P1	
RFHT	IHT INCO P2
OFST	BS m/f/i P3

Coordinate measurement mode

HR:	157°	33'	58"
VZ:	81°	54'	21"
SD:	1.425m		
HD:	0.645m		
VD:	1.271m		
DIST	MODE	S/A	P1
OFST	S.O.	m/f/i	P2

Distance measurement mode


## Descriptions

Mode		Display mark	Soft key	Function
Angle measurement	P1	0SET	F1	Horizontal angle is set to 0
		HOLD	F2	Hold the horizontal angle
		HSET	F3	Setting horizontal angle by input values
	P2	TILT	F1	Setting tilt compensator on/off
		REMS	F2	Enter repeat angle measurement program
		V%	F3	Switch grade/zenith distance VZ
	P3	HABZ	F1	Buzzer set for every horizontal angle 90°
		HARL	F2	Switch horizontal angle mode (HR/HL)
		CMPS	F3	Set a vertical angle mode(VH/VZ)
S-distance meas.	P1	DIST	F1	Start distance measurement
		MODE	F2	Select the measurement model as fine or track
		S/A	F3	EDM setting
	P2	OFST	F1	Select Offset measurement program
		S.O.	F2	Select stake out measurement program
		m/f/i	F3	Change the display of distance unit
Coordinate meas.	P1	DIST	F1	Start distance measurement
		MODE	F2	Select the measurement model as fine or track
		S/A	F3	EDM setting
	P2	RFHT	F1	Set prism height
		IHT	F2	Set instrument height
		INCO	F3	Sets occupied station coordinate
	P3	OFST	F1	Enter offset measurement program
		BS	F2	Sets back sight point coordinate
		m/f/i	F3	Change the distance unit

## 2. Battery

### 2.1 Mounting the battery

(1) Insert the battery by aligning the battery pack's tenon with the notch in the instrument, press the battery clamp and push the top of the battery pack until you hear a click.




### (2) Removing the battery

Press the battery clamp and remove the battery pack by pulling it toward you.


### (3) Battery Indicator

Battery power display indicates the power condition. You should recharge or replace the battery when you hear the continue buzz.



Please turn off in the normal way in order to save the data. Please find the battery operating time on Specifications.

### Battery power display



## 2.2 Recharge



1. Plug the charger on 220V-110V AC power supply, the red lamp lighting.
2. When recharge is complete, the light become green. Normally, it will take about 3-4 hours.

Caution: For indoor use only.

### **Note:**

1. The new battery (or not be used for long time) need to recharge and discharge for several times, the battery could become the good performance for using. Please recharge more than 10 hours.
2. Please prolong charge 1-2 hours after green lamp lighting to reach the best performance.
3. Lamp situation: red lamp lighting--charging; green lamp lighting--charge complete; red lamp flash--waiting, not connecting or battery defective.
4. If the red lamp flashes when plug the charger, please remove the charger and wait a minute to plug it again.

### 3. Preparation for measurement

#### 3.1 Setting up the instrument

##### (1) Setting up the tripod

First, extend the extension legs to suitable lengths and tighten the screws on the midsections

##### (2) Attaching the instrument on the tripod head

Place the instrument carefully on the tripod head and slide the instrument by loosening the tripod screw.

#### 3.2 Leveling the instrument

##### (1) Leveling with the circular level





by adjusting leveling screws A and B, position the bubble in the center of vial (Fig a).

Adjust the leveling screw C, position the bubble in the center of circle (Fig b).

##### (2) Leveling precisely by plate level

Loosen horizontal motion clamp, place the plate level in parallel with the line joining leveling screws A and B. Adjust the leveling screws A and B, position the bubble in the center of the plate level (Fig c).

Loosen horizontal motion clamp,




rotate the plate level through  $90^\circ$  around the vertical axis. Adjust leveling screw C, position the bubble in the center of plate level (Fig d).

Repeat above steps until the bubble remains in the center of plate level while the instrument is rotated to any position.

### 3.3 Centering

#### 3.3.1 Centering with optical plummet

Leveling the instrument by plate level first. Rotate the focusing ring of the optical plummet and adjust the focus to the ground mark point. Then loosen the center screw of the tripod, look through the optical plummet, and move the base plate on the tripod head until the center mark coincides with the ground mark point. At last tighten the center screw. Repeat above steps to leveling the instrument again, until the center of reticle coincides with the mark point when rotating alidade of instrument.



#### 3.3.2 Centering with laser plummet

Laser Point Adjust  
Level: 4

+   —   —   ENT

- (1) Press ★ key to open fast setting menu, and press F4 to open plummet laser intensity adjusting menu, press F1 to increase laser intensity, or press F2 to decrease laser intensity, at last press F4(ENT) to confirm.
- (2) Turn the focusing knob until the laser spot on the same horizontal plane with mark point on the ground.
- (3) Loosen the center screw of the tripod, and move the base plate on the tripod head until the laser spot coincides with the ground mark point. Tighten the center screw.
- (4) Repeat leveling and (3) steps until the instrument keeps leveling and the laser spot coincides with the mark point when rotating alidade of instrument to any direction.
- (5) After centering, please press [ESC] key.




### 3.4 Focusing

#### (1) Diopter adjustment

Point telescope to sky or a uniformly light surface (Do not point to the sun). Turn eyepiece until cross hairs are sharp and black.

#### (2) Target image focusing

Look through telescope eyepiece and turn focusing ring until target is seen. There should be no apparent movement between cross hairs and target as observer moves his eye slightly. If there is parallax, please remove it by adjusting the focusing ring slightly.




### 3.5 Switch on

1. Confirm the instrument is leveled and centered.

2. Press power key to switch on.

3. It will show the software version and model first, then to show LCD Contrast adjusting screen. It also shows current prism constant value (PSM) and atmospheric correction value (PPM). You could press F1 or F2 to adjust the contrast. Then press F4 to confirm and enter basic measurement mode.

Check the battery power indicator, recharge battery when battery level is low or indicates “battery empty”.




Flow chart for switch on

### 3.6 Switch off

(1) Press power key.

(2) Press F3 to switch off; Press F4 back to the latest page.







Flow chart for switch off

### 3.7 The function of ★ key menu

Item	Functions	Operating keys
Backlight	Backlight on or off	F1
Laser Point	Laser pointer On/Off	F2
Target Type	Target setting PRISM/SHEET/No PRISM / LPRISM	F3
Laser plummet	Laser plummet intensity adjusting	F4
EDM	EDM settings	F1
Tilt	TILT on or off	F2
CONTRAST	Display contrast adjusting	F3

### 3.8 How to input number and letter

For ALPHA X series, the number and letter can input with keyboard directly. Example: Create one file for data collect program

Operating procedure	Operation	Display
①Enter the menu by press the [MENU] key.	[MENU]	
②Press [F1] key to enter file selecting screen, press the [F1](INPT) key to rename file name. And press [F1] to switch inputting mode from number to letter(ALPH).	[F1]  [F1]  [F1]	
③Input letter one by one ※1) Input “S” Move the cursor Input “U” Input “N” Input “-”	[7] ► [7][7][7] [5][5] [-]	
④Press [F1](ALPH) key to switch inputting mode from letter to number. Input “01”	[F1] [0][1]	 <p>After input a number, the cursor will move backward automatically</p>
⑤Press the [F4] key to confirm		
<p>※1) If one letter need to be input twice or more, after input the front letter, press the ► key to move cursor, then input the following letter again. Press F2 (SPC) key to enter a space. Press F3[CLR]key, all the input characters will be deleted.</p>		




### 3.9 Vertical Angle Tilt Correction

When the tilt sensors are activated, automatic correction of vertical angle for mislevelment is displayed.

To ensure a precise angle measurement, tilt sensors should be turned on. The display can also be used to precise level the instrument. If the display(X/Y Tilt over) appears the instrument is out of automatic compensation range and must be leveled manually.

The vertical angle display is unstable when instrument is on an unstable stage or a windy day. You can turn off the auto tilt correction function in this case.

Example: Setting Tilt OFF

Operating procedure	Operation	Display
①Under Angle measurement mode, press[F4] to enter P2.	[F4]	
②Press [F1] key. In case ON is already selected, the display shows tilt correction value.※1)	[F1]	
③Press[F3](OFF) key. ④Press[ESC]key.	[ F3] [ESC]	

※1) The setting mode performed here will not be memorized after powering OFF. To set TILT correction in the initialized setting ( it is memorized after powering OFF).

## 4. Angle Measurement

### 4.1 Measuring Horizontal Angle (Right) and Vertical Angle

Make sure the mode is in Angle measurement

Operating procedure	Operation	Display
①Collimate the 1st target (A).	Collimate A	<div>VZ: 89° 25' 55"</div> <div>HR: 157° 33' 58"</div> <div>0SET HOLD HSET P1</div>
②Set horizontal angle of target A at 0°00'00, press the [F1](0SET) key and press the [F3] (YES) key.	[F1] [F3]	<div>H-ANG SET0</div> <div>&gt;SET?</div> <div>--- --- YES NO</div>
③Collimate the 2nd target (B).The horizontal angle between B and A and vertical angle of B be displayed.	Collimate B	<div>VZ: 89° 25' 55"</div> <div>HR: 0° 00' 00"</div> <div>0SET HOLD HSET P1</div>
		<div>VZ: 124° 34' 20"</div> <div>HR: 56° 21' 01"</div> <div>0SET HOLD HSET P1</div>

Reference: How to Collimate

①Point the telescope toward the light back ground. Turn the diopter ring and adjust the diopter so that the cross hairs are clearly observed.

②Aim the target at the cross hair of the sighting collimator. Allow a certain space between the sighting collimator and yourself for collimating.



③Focus the target with the focusing knob.

※If parallax is created between the cross hairs and the target when your eyes move vertically or horizontally, focusing is incorrect or diopter adjustment is poor. This affects precision in measurement.

Eliminate the parallax by carefully focusing and using diopter adjustment.

## 4.2 Switching Horizontal Angle Right/ Left




Make sure the mode is Angle measurement.

Operating procedure	Operation	Display
①Press the [F4] key twice to get the function on page3.	[F4] [F4]	<div> VZ: 89° 25' 55"  HR: 168° 36' 18"   </div> <div> HABZ HARL CMPS P3 </div>
②Press [F2] (HARL) key. The mode Horizontal angle Right (HR) Switches to (HL) mode.	[F2]	<div> VZ: 89° 25' 55"  HL: 191° 23' 42"   </div> <div> HABZ HARL CMPS P3 </div>
③Measure at HL mode as HR mode.		
<p>●Every time pressing the [F2] (HARL) key, HR/HL mode switches alternately.</p>		

### 4.3 Set a Horizontal Angle




#### 1) Setting by Holding the Horizontal Angle

Make sure the mode is angle measurement

Operating procedure	Operation	Display
<p>①Set the required horizontal angle, using Horizontal tangent screw</p> <p>②Press[F2](HOLD) key.</p> <p>③Collimate the target. ※1)</p> <p>④Press [F3](YES) key to finish holding the horizontal angle. The display turns back to angle measurement mode.</p>	<p>Display angle</p> <p>[F2]</p> <p>[F3]</p>	<div> VZ: 89° 25' 55"  HR: 191° 23' 42"  0SET HOLD HSET P1  </div> <div> H-ANG HOLD  HR: 191° 23' 42"  --- --- YES NO  </div> <div> VZ: 89° 25' 55"  HR: 191° 23' 42"  0SET HOLD HSET P1  </div>
<p>※1) To return to the previous mode, press the [F4] (NO) key.</p>		

## 2) Setting a horizontal angle by the number key



Make sure the mode is Angle measurement

Operating procedure	Operation	Display
<p>①Collimate the target.</p> <p>②Press[F3](HSET)key.</p> <p>③Input the required horizontal angle by using keys.※1 For example:80°30'50"</p> <p>④Press[F4] to set the horizontal angle.</p>	<p>Collimate</p> <p>[F3]</p> <p>[F1]</p> <p>[80.3050]</p> <p>[F4]</p>	<div> VZ: 89° 25' 55"  HR: 168° 36' 18" "  0SET HOLD HSET P1  </div> <div> H-ANG SET  HR= 80.3050  — — CLR ENT  </div> <div> VZ: 89° 25' 55"  HR: 80° 30' 50"  0SET HOLD HSET P1  </div>
<p>※1) If input is mistake, press [MENU] (👉)or [F3](CLR) to cancel the input. If the input fault, you have to repeat step from ③.</p>		





## 4.4 Vertical Angle Grade Mode Switch

Make sure the mode is Angle measurement

Operating procedure	Operation	Display
① Press [F4] key to get the function on page 2.	[F4]	<div> VZ: 67° 38' 15"  HR: 168° 36' 19"   </div> <div> 0SET HOLD HSET P1 </div>
② Press [F3](V%) key. ※1)	[F3]	<div> TILT REMS V% P2 </div> <div> V: 41.13%  HL: 168° 36' 19"   </div> <div> TILT REMS V% P2 </div>
※1) Every time pressing the [F3] (V%) key, the display mode switches.		

## 4.5 Zenith distance/ vertical angle mode switch

Make sure the mode is Angle measurement




Operating procedure	Operation	Display
① Press [F4] (P1) key to get the function on page 3.	[F4]	<div> Vz: 67° 38' 15"  HR: 168° 36' 19"   </div> <div> 0SET HOLD HSET P1 </div> <div> HABZ HARL CMPS P3 </div>
② Press [F3] (CMPS) key. ※1)	[F3]	<div> VH: 22° 21' 42"  HL: 168° 36' 19"   </div> <div> HABZ HARL CMPS P3 </div>
※1) Every time press the [F3] key, the display mode switches. ● At VH mode, vertical angle is 0 when telescope is in horizontal direction.		

## 4.6 Set Buzzer Sounding for Horizontal Angle 90°

When the horizontal angle falls in the range of  $\pm 1^\circ$  of  $0^\circ, 90^\circ, 180^\circ$  or  $270^\circ$ , the buzzer sounds. Buzzer stops only when the horizontal angle is adjusted to  $0^\circ 00' 00''$ ,  $90^\circ 00' 00''$ ,  $180^\circ 00' 00''$  or  $270^\circ 00' 00''$ .

This setting is not memorized after powering off.






Make sure the mode is Angle measurement

Operating procedure	Operation	Display
① Press the [F4] key twice to get the function on page 3.	[F4][F4]	<div>Vz: 89° 25' 55"</div> <div>HR: 168° 36' 19" </div> <div>0SET HOLD HEST P1</div> <div>TILT REMS V% P2</div> <div>HABZ HARL CMPS P3</div>
② Press [F1] key.	[F1]	<div>HA Buzzer</div> <div>[F1:ON]</div> <div>F2:OFF </div> <div>ENT</div>
③ Press [F1] (ON) key or [F2] (OFF) key to select the buzzer ON/OFF.	[F1] or [F2]	<div>HA Buzzer</div> <div>[F1:ON]</div> <div>F2:OFF </div> <div>ENT</div>
④ Press [F4] key to set.	[F4]	<div>VZ: 89° 25' 55"</div> <div>HR: 168° 36' 18"</div> <div>HABZ HARL CMPS P3</div>

## 5. Distance Measurement

### 5.1 Distance Measurement (Slope distance mode)

Make sure the mode is angle measurement.

Operating procedure	Operation	Display
①Press  key.		<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 0.000m            HD: 0.000m            VD: 0.000m            DIST MODE S/A P1         </div> 
②Collimate the center of prism.		
③Press[F1]key to start measure distance.※1)	[F1]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD*[r]-&lt; m            HD: 0.000m            VD: 0.000m            DIST MODE S/A P1         </div> 
④The measured distance are shown.※2)~※4)		<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            HD: 0.645m            VD: 1.271m            DIST MODE S/A P1         </div> 
※1) When EDM is working, the“- <”mark appears in the display. ※2) The measured distance appears with buzzer sounds. ※3) The displayed measured distance values depend on the different measurement mode. When the mode is Single measurement, the value is the current measured distance; When the mode is Continuous measurement, the latest display is the average value; When the mode is tracking measurement, the measured distance precision is 0.01m. ※4) If the target is covered, distance can't be measured. Please make sure there is nothing between the target and instrument telescope.		


## 5.2 Stake out (S.O)

The difference between the measured distance and the input stake out distance is displayed.

Displayed value=Measured distances-Stake out distance

In stake out operation, you can select either horizontal distance (HD), relative elevation(VD)or slope distance (SD).

Make sure the mode is Distance measurement

Operating procedure	Operation	Display
①Press [F4] (P1) key from distance measuring mode to get the function on page 2.	[F4]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            HD: 0.645m            VD: 1.271m            DIST MODE S/A P1         </div>
②Press [F2] (S.O) key.	[F2]	<div>           OFST S.O m/f/i P2         </div>
③Press[F1](HD) key.※1)		<div>           SET OUT            HD: 0.000m         </div>
④Enter the distance for stake out and press [F4] key. Collimate the prism.	[F1]	<div>           HD VD SD ---         </div>
	[F4]	<div>           SET OUT            HD: 10.000m             ---- CLR ENT         </div>
⑤Press [F4] key to return P1, press [F1] to start measuring. +value means move prism toward the instrument. -value means move prism backward the instrument.	[F4] [F1]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            dHD: -0.285m            VD: 1.271m            DIST MODE S/A P1         </div> <div>  </div>
※1) At step ④, if we set the stake out distance as 0, the program will		

return to normal distance measurement mode.

### 5.3 Set distance measurement mode

There are three modes that can be selected: F1: FINE, F2: TRK, F3: RAP

For F1: FINE mode, press [DIST] key to measure distance according to the set times, the first measuring time is about 3s, minimum reading is 1mm.

For F2: TRK mode, press [DIST] key to measure distance continuously until press [ESC] key, the first measuring time is about 2s, minimum reading is 10mm.

For F3: RAP mode, press [DIST] key to measure distance according to the set times, the first measuring time is about 2s, minimum reading is 1mm.

Make sure the mode is Distance measurement

Operating procedure	Operation	Display
① Press[F2](MODE) key.	[F2]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            dHD: -0.285m            VD: 1.271m            DIST MODE S/A P1         </div>
② Press [F1](FINE),[F2](TRK) or [F3](RAP) to change to the required mode, and it will be back to normal measurement screen.	[F1],[F2] or [F3]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            dHD: -0.285m            VD: 1.271m            FINE TRK RAP         </div>

## 5.4 Set distance unit

Make sure the mode is Distance measurement

Operating procedure	Operation	Display
① Press[F4](P1) key from distance measuring mode to get the function on page 2.	[F4]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            dHD: -0.285m            VD: 1.271m            DIST MODE S/A P1         </div>
② Every time press [F3](m/f/i), the current unit will change among m, ft, inch in sequence.	[F3]	<div>           OFST S.O m/f/i P2         </div>

## 5.5 Setting of the Atmospheric Correction

These series of total stations can realize the atmospheric correction by inputting directly the temperature and pressure value.

Make sure the mode is Distance measurement.

Operating procedure	Operation	Display
① Press [F3]key(S/A) to enter EDM SET mode.	[F3]	<div>HR: 157° 33' 58"</div> <div>VZ: 81° 54' 21"</div> <div>SD: 1.425m</div> <div>dHD: -0.285m</div> <div>VD: 1.271m</div> <div>DIST MODE S/A P1</div>
② Press [F3] key.	[F3]	<div>EDM SET</div> <div>PSM-30.0 PPM -1.9</div> <div>Signal: [ ]</div> <div>PSM PPM T-P TIMS</div>
③ Input the temperature and pressure values. Press[F4]key to save the setting.	[F4]	<div>T&amp;P</div> <div>TEMP = 18.0_ ° C</div> <div>PRES : 1020.0 hPa</div> <div>--- --- CLR ENT</div>
		<div>T&amp;P</div> <div>TEMP = 25_ ° C</div> <div>PRES : 1020.0 hPa</div> <div>--- --- CLR ENT</div>

Note: One EDM SET page you can also press PSM to input prism constant or press PPM to directly set PPM value.

The atmospheric correction is little effect on distance measurement. But if the input Temp. value and pressure value is big different from the measuring value, the distance different should be more than 0.001m.

Input range: -40.0°C < Temperature < +60.0°C

-40.0°F < Temperature < +140.0°F

Input range: +500.0hpa < Pressure < +1500.0hpa

+500.0mbar < Pressure < +1500.0mbar

+375.0mmHg < Pressure < +1125.0mmHg

+14.8inhg < Pressure < +44.3inhg

+7.3psi < Pressure < +21.8hpa

## 5.6 Returned signal Checking

Check to make sure that sufficient reflected light is returned by the reflective prism sighted by the telescope. Make sure the mode is Distance measurement.

Operating procedure	Operation	Display
① Press [F3]key(S/A) to enter EDM SET mode.	[F3]	<div>           HR: 157° 33' 58"            VZ: 81° 54' 21"            SD: 1.425m            dHD: -0.285m            VD: 1.271m            DIST MODE S/A P1         </div>
② The intensity of current returned signal is shown on the third line..		<div>           EDM SET            PSM-30.0 PPM -1.9            Signal: [ ]            PSM PPM T-P TIMS         </div>
③ Press[ESC]key to return the previous mode.	[ESC]	



## 5.7 Setting distance measurement times (Factory setting is “3”)

Make sure the mode is Distance measurement.


Operating procedure	Operation	Display
① Press [F3]key(S/A) to enter EDM SET mode.	[F3]	<div>HR: 157° 33' 58"</div> <div>VZ: 81° 54' 21"</div> <div>SD: 1.425m</div> <div>dHD: -0.285m</div> <div>VD: 1.271m</div> <div>DIST MODE S/A P1</div> <div>EDM SET</div> <div>PSM-30.0 PPM -1.9</div> <div>Signal: [ ]</div> <div>PSM PPM T-P TMS</div>
② Press [F4] key.	[F4]	<div>DIST TIMES SET</div> <div>TIMES=3_</div> <div>--- --- CLR ENT</div>
③ Input the distance measurement times. Press[F4]key to save the setting.	[F4]	<div>DIST TIMES SET</div> <div>TIMES=5_</div> <div>--- --- CLR ENT</div>

NOTE: It is not possible to set the times as “0”. The appropriate time is “3”, which is better for saving power and high accuracy. The range is between 1 and 99.

## 6. Coordinate Measurement



Set the coordinates of the instrument (occupied point) and backsight point, the instrument can measure and displays the unknown point (prism point) coordinates

Press [ $\angle$ ] key to switch to coordinate measurement mode.





## 6.1 Setting Coordinate of Occupied point

### 1) Coordinate data input by keyboard directly

Operating procedure	Operation	Display
①Press  key.		<div>N : 0.000m E : 0.000m Z : 0.000m DIST MODE S/A P1</div>
②Press [F4] key to display the function page2.	[F4]	<div>RFHT IHT INCO P2</div>
③Press [F3] (INCO) key. ※1)	[F3]	<div>N = 0.000_ m E : 0.000m Z : 0.000m --- --- CLR ENT</div>
④Enter the coordinate. ※2)	Enter	<div>N : 123.456m E : -987.015m Z : 0.803 m --- --- CLR ENT</div>
⑤After NEZ coordinate is entered, press [F4] to confirm, the instrument returns coordinate measurement menu on page 2.	NEZ data	
	[F4]	
<p>※1) “=”means the current entering item, the item can be entered right now. After enter and press [F4] key, the“=” moves to the next line. If this item need not to enter, press [F4] key to move “=” directly.</p> <p>※2) Input range: -99999999.9990m&lt; N,E,Z&lt; +99999999.9990m Input range: -99999999.9990ft&lt; N,E,Z&lt; +99999999.9990ft Input range: -99999999.11.7ft+in&lt; N,E,Z&lt; +99999999.11.7ft+in</p>		



## 6.2 Setting of instrument height

After power off, the instrument height can be saved.

Operating procedure	Operation	Display
① Press [  .] key.	[  .]	<div>N : 123.456m</div> <div>E : -987.015m</div> <div>Z : 0.803 m</div> <div>DIST MODE S/A P1</div>
② Press [F4] key to display the function page2.	[F4]	<div>RFHT IHT INCO P2</div>
③ Press [F2] (IHT) key.	[F2]	<div>INSTRUMETN</div> <div>HEIGHT INPUT</div> <div>Ins.Hi=1.174_ m</div> <div>--- --- CLR ENT</div>
④ Enter the instrument height, press F4 to confirm, the instrument returns coordinate measurement menu on page 2.	Enter	
※1)	Inst.H	
	[F4]	<div>N : 123.456m</div> <div>E : -987.015m</div> <div>Z : 0.803 m</div> <div>RFHT IHT INCO P2</div>
※1) Input range: -999.9990m< Inst.H< +999.9990m Input range: -999.9990ft< Inst.H< +999.999ft Input range: -999.11.7 ft+in< Inst.H< +999.11.7 ft+in		


### 6.3 Setting of target height

After power off, the target height can be saved.

Operating procedure	Operation	Display
①Press  key .		<div>N : 123.456m</div> <div>E : -987.015m</div> <div>Z : 0.803 m</div> <div>DIST MODE S/A P1</div> <div>RFHT IHT INCO P2</div>
②Press[F4]key to display the function page2.	[F4]	
③Press[F1](RFHT)key.	[F1]	<div>REF HT INPUT</div> <div>Ref.Hr=2.500_ m</div> <div>--- --- CLR ENT</div>
④Enter the target height, press F4 to confirm, the instrument returns coordinate measurement menu on page 2..	Enter Targ.H	
※1)	[F4]	<div>N : 123.456m</div> <div>E : -987.015m</div> <div>Z : 0.803 m</div> <div>RFHT IHT INCO P2</div>
※1) Input range: -999.9990m< Ref.H< +999.9990m Input range: -999.9990ft< Ref.H< +999.9990ft Input range: -999.11.7 ft+in< Inst.H< +999.11.7 ft+in		



## 6.4 Setting coordinate of backsight point

### Direct key input of coordinate data

Operating procedure	Operation	Display
①Displaying the coordinate measurement mode on page 3.		<div>N : 123.456m</div> <div>E : -987.015m</div> <div>Z : 0.803 m </div> <div>DIST MODE S/A P1</div> <div>RFHT IHT INCO P2</div> <div>OFST BS m/f/i P3</div>
②Press [F2] key to get the function of setting backsight point.	[F2]	<div>N= 0.000_ m</div> <div>E : 0.000m</div> <div>Z: 0.000m</div> <div>--- --- CLR ENT</div>
③Enter the coordinate.	Input	<div>N= <u>0</u>.000m</div> <div>E : 0.000m</div> <div>Z: 0.000m</div> <div>--- --- CLR ENT</div>
④After NEZ coordinate is entered; press [F4] to confirm.	N,E,Z [F4]	
⑤Collimate backsight point prism center, press [F3] (YES) key. The azimuth angle is set, and instrument returns coordinate measurement menu on page 3.	AIM [F3]	<div>BACKSIGHT</div> <div>HR: 12° 34' 56"</div> <div>&gt;Sight?</div> <div>YES NO</div>
		<div>N : 123.456m</div> <div>E : -987.015m</div> <div>Z : 0.803 m</div> <div>OFST BS m/f/i P3</div>

## 6.5 Measuring point coordinate


After setting the coordinate of instrument and backsight, instrument height and target height, collimate the point to measure its coordinate.

Operating procedure	Operation	Display
①In coordinate measurement mode function page1.	Collimate [F1]	<div> N : 123.456m  E : 987.654m  Z 1.000m   DIST MODE S/A P1 </div>
②Collimate prism, press [F1] key, the instrument begins to measure distance and then give the final result.		<div> N: 123.456m  E:*[3]-&lt; m  Z -2.345m   DIST MODE S/A P1 </div>

## 7. Data collection

These series of total stations are able to store the measured data into the internal memory. The internal memory is shared by the measured data files and the coordinate data files.

### 7.1 Data collection menu operation





## 7.2 Selecting a file for data collection

Select a file before beginning data collection. The measured data could be stored into the selected file.

Operating procedure	Operation	Display
①Press [MENU] key enter the menu display.	[MENU]	<div>MENU 1/2 ↓</div> <div>F1:DATA COLLECT</div> <div>F2:LAYOUT</div> <div>F3:MEMORY MGR.</div> <div>F4:PROGRAMS</div>
②Press [F1] key enter data collection.	[F1]	<div>SELECT A M.FILE</div> <div>FN:</div> <div>INPT LIST --- ENT</div>
③Press [F2] key to display the file list. ※1)	[F2]	<div>&gt; *1 /M0003</div> <div>1SV /M0000</div> <div>TOP LAST SRCH ENT</div>
④Scroll file list by pressing [▲]or [▼] key and select one file to use.※2)	[▲] [▼]	<div>1 /M0003</div> <div>&gt;*1SV /M0000</div> <div>S /M0000</div> <div>TOP LAST SRCH ENT</div>
⑤Press [F4] key. The file will be set.	[F4]	<div>COLLECT 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: FS/SS</div> <div>F4: SELECT A FILE</div>
<p>※1) If you want to input file name directly, press[F1] key and enter a file name.</p> <p>※2) When a file has been selected already, “*”mark is indicated on left of current file name.</p>		

## 7.3 Selecting a coordinate file for data collection

When coordinate data in a coordinate data file are used for occupied

point or backsight point, select a coordinate file beforehand.

Operating procedure	Operation	Display
① On data collection menu press [F4]key.	[F4]	<div>COLLECT 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: FS/SS</div> <div>F4: SELECT A FILE</div>
② Press [F2] key.	[F2]	<div>SELECT A FILE</div> <div>F1: MEAS. FILE</div> <div>F2: COORD. FILE</div>
④ Press[F2] key to display the list of file.	[F2]	<div>SELECT A C.FILE</div> <div>FN:</div> <div>INPT LIST --- ENT</div>
⑤ Scroll file list by pressing [▲]or [▼] key and select a file to use.	[▲] or [▼]	<div>&gt; @A-GEO_01 /C0012</div> <div>A-GEO_02 /C0102</div> <div>A-GEO_03 /C0008</div> <div>TOP LAST SRCH ENT</div>
⑥ Press [F4]key. The file will be set.	[F4]	<div>A-GEO_01 /C0012</div> <div>&gt; @A-GEO_02 /C0102</div> <div>A-GEO_03 /C0008</div> <div>TOP LAST SRCH ENT</div>
		<div>COLLECT 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: FS/SS</div> <div>F4: SELECT A FILE</div>
※1) If you want to input file name directly, press[F1] key and enter a file name.		

※2) When a file has been selected already, “@” mark is indicated on left of current file name.

## 7.4 Occupied Point Setting

1) Setting the coordinate data from the internal memory.

Operating procedure	Operation	Display
①Make sure the displaying is Data Collect menu.		<div>COLLECT 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: FS/SS</div> <div>F4: SELECT A FILE</div>
②Press [F1] (OCC. PT# INPUT) key, displays PT# input menu.	[F1]	<div>PT# &gt;</div> <div>PCODE :</div> <div>Ins.Hi : 1.000 m</div> <div>INPT SRCH REC STN</div>
③Press [F4] key.	[F4]	<div>OCC. PT</div> <div>PT#:</div> <div>INPT LIST NEZ ENT</div>
④Press[F2] key to display the list of PT#.※1)	[F2]	<div>[AGEO ]</div> <div>&gt; F001</div> <div>F002</div> <div>VIEW SRCH --- ENT</div>
⑤Scroll PT# list by pressing [▲] or [▼] key and select PT#. Press [F4] key.	[▲]or [▼] [F4]	<div>N 5.620m</div> <div>E 4.210m</div> <div>Z 1.250m</div> <div>&gt;OK? NO YES</div>
※2) ※3)		
⑥Press [F4] to select YES.	[F3]	
⑦Enter Ins. Hi, PCODE,		

Press [F3] key. ※4)		
※1) If you want to input PT# directly, press [F1]key and enter PT#. ※2) The coordinate data can be viewed by press [F1](VIEW)key. ※3) The coordinate data can be searched by press [F2](SRCH) key. ※4) If the input number is 0-50, it should be ID of PCODE in library.		

## 2) Input the instrument point coordinates by hand

Operating procedure	Operation	Display
---------------------	-----------	---------

<p>① Make sure the displaying is Data Collect menu.</p> <p>② Press[F1]( OCC.PT# INPUT) key , displays PT# input menu.</p> <p>③ Press [F4] key.</p> <p>④ Press [F3] (NEZ) to enter coordinate input menu.</p> <p>⑤ Press[F4]key and enter coordinate point number. Press[F4]key to confirm.</p> <p>⑥ Input the PCODE and Ins.Hi and then press [F3] to record</p>	<p>[F1]</p> <p>[F4]</p> <p>[F3] [F1] Input coord</p> <p>[F4] point number</p> <p>[F4]</p> <p>[F3]</p>	<div data-bbox="629 135 951 290"> <p>COLLECT 1/2 ↓ F1: OCC. PT# INPUT F2: BACKSIGHT F3: FS/SS F4: SELECT A FILE</p> </div> <div data-bbox="629 302 951 458"> <p>PT# &gt;0 PCODE:PV Ins.Hi: 1.000 m INPT SRCH REC STN</p> </div> <div data-bbox="629 470 951 626"> <p>OCC. PT PT#:0  INPT LIST NEZ ENT</p> </div> <div data-bbox="629 638 951 793"> <p>OCC. PT N: 123.456 m E: 987.654 m Z&gt; -1.608 m --- --- CLR ENT</p> </div> <div data-bbox="624 900 945 1056"> <p>PT# &gt;5 PCODE : Ins.Hi: 1.000 m INPT SRCH REC STN</p> </div> <div data-bbox="624 1098 945 1253"> <p>PT# :5 PCODE : Ins.Hi: 1.000 m INPT SRCH REC STN</p> </div>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 7.5 Backsight Point

### 1) Setting the coordinate data from the internal memory

Make sure the mode is Data Collect.

Operating procedure	Operation	Display
① Make sure the displaying is Data Collect menu.		COLLECT 1/2 ↓ F1: OCC. PT# INPUT F2: BACKSIGHT F3: FS/SS F4: SELECT A FILE
② Press [F2] (BACK SIGHT) key.	[F2]	BS# > PCODE: Ref.Hr: 0.000m INPT OSET MEAS BS
③ Press [F4] (BS) key. ※1)	[F4]	BACK SIGHT PT# : INPT LIST NEAZ ENT
④ Press [F1] key and enter PT#. ※2)	[F1] Input PT#	BACK SIGHT PT# =F002_
⑤ Press [F4] key, the coordinate will display	[F4]	ALPH SPC CLR ENT
⑥ Press [F4] (YES) key.	[F4]	N: 22.000m E: 123.210m Z: 100.000m >OK? [NO] [YES]
⑦ Collimate backsight point, press [F3] (YES) key. ※3)	[F3]	BACKSIAHT HL :179° 59' 07" >Sight? dHD YES NO
The display returns to BS menu, press [ESC] return to Data Collect main menu.		BS# >F002 PCODE : Ref.Hr: 0.000m INPT BS MEAS OSET

- ※1) The coordinate data can be searched by press [F2](LIST)key.
- ※2) Press [F3] key, backsight setting mode will be switched among NEAZ/AZ/PT#.
- ※3) Press [F1](dHD) to measure the horizontal difference between calculated Backsight and true backsight.

## 2) Setting the direction angle

Make sure the mode is Data Collect.

Operating procedure	Operation	Display
① Make sure the displaying is Data Collect menu.	[F2]	COLLECT 1/2 ↓ F1: OCC. PT# INPUT F2: BACKSIGHT F3: FS/SS F4: SELECT A FILE
② Press [F2](BACK SIGHT) key.	[F3]	BS# > PCODE: Ref.Hr: 0.000m INPT OSET MEAS BS
③ Press [F4](BS) key. ※1)	[F3]	BACK SIGHT PT# : INPT LIST NEAZ ENT
④ Press [F3] twice to enter AZ inputting menu.	[F1] [186.5600]	BACK SIGHT HR: INPT --- PT# ENT
⑤ Press [F1] key, input the direction angle. 186°56'00" Press [F4] key.	[F4]	BACK SIGHT HR=186.5600_ --- --- CLR ENT
⑥ Collimate backsight point, press [F3]key. The display returns to BS menu.	Collimate backsight point [F3]	BACKSIAHT HL:186° 56' 00" >Sight? YES NO

## 7.6 Operational Procedure of “Data Collect”

Make sure the mode is Data Collect.

Operating procedure	Operation	Display
① Press [F3] (FS/SS) key.	[F3]	PT# > PCODE : 0 Ref.Hr: 0.000m INPT SRCH MEAS ALL
② Press [F1] key and input PT#, PCODE, Ref.Hr. Press [F3](MEAS)key. ※1)	[F1]  [F3]	PT# :F021 PCODE : AGE0 Ref.Hr: 1.000m VH HD NEZ OFST
③ There are four modes can be selected, press [F2](HD) key, HD/VD data will be measured.※2) ※3)	[F2]	HR: 0° 00' 00" HD: m VD -< <Measuring>
④ Press [F3](YES) to record the measured data to memory.※4)	[F3]	HA: 58° 14' 22" HD: 56.461 m VD: 5.625 m >OK [YES] [NO]
⑤ The display changes to previous menu, and it is ready to measure next point. PT# is automatically incremented. Press [F4] (ALL) key to measure next point in the same measuring mode(HD) with previous point.※5)	[F4]	PT# :F022 PCODE : AGE0 Ref.Hr: 1.000m INPT SRCH MEAS ALL  HR: 180° 05' 18" HD: m VD -< <Measuring>



※6)

※1) When the mark “>” is located PCODE, PCODE can be input directly, or recall by inputting a register number linked with PCODE Library. To show the list of PCODE library, press the [F2] (SRCH)

※2) VH means the measured data is in angle format, the HD/SD means the data is in angle and distance format, NEZ means the data is in coordinate format.

※3) In DATA COLLECT/CONFIG/F1:HD/SD menu, if current setting is SD, here SD is displayed to be set

※4) In DATA COLLECT/CONFIG/F3:DATA CONFIRM menu, if current setting is NO, this asking screen will not display and the measured data will be recorded automatically.

※5) Press F4 (ALL) to measure next point, the PT# will increase one automatically, PCODE and the Ref.Hr, and distance measurement mode will not change, according to your need to edit every item before selecting ALL.

※6) While executing the DATA COLLECT mode, you can search the recorded data.

● While executing the DATA COLLECT mode, press [F2](SRCH) key.

● Select one of three search methods by pressing [F1] to [F3] key

The operation is same as the "SEARCH" in the MEMORY MANAGER mode.

PT#	:F022
ID	:AGEO
Ref.Hr:	1.000m
INPT	SRCH MEAS ALL

MEAS.DATA SEARCH	
F1:	FIRST DATA
F2:	LAST DATA
F3:	PT# DATA

## 7.7 Setting PCODE for measured point

### 7.7.1 Entering PCODE / ID using PCODE Library

While executing the DATA COLLECT mode, you can enter PCODE /ID from PCODE Library.

Operating procedure	Operation	Display
①Move the arrow to the PCODE		<div>PT# :F023</div> <div>PCODE &gt;</div> <div>Ref.Hr: 0.000m</div> <div>INPT SRCH MEAS ALL</div>
②Press [F1]to enter a register number linked with PCODE library and press the [F4](ENT) key. (Example) Register number, 12 = AGE0	[F1] Input ID of PCODE [F4]	<div>PT# :F023</div> <div>PCODE =12_</div> <div>Ref.Hr: 0.000m</div> <div>NUM SPC CLR ENT</div>
		<div>PT# :F023</div> <div>PCODE :AGE0</div> <div>Ref.Hr&gt; 0.000m</div> <div>INPT SRCH MEAS ALL</div>

### 7.7.2 Entering PCODE / ID from the list of PCODE

You can also enter PCODE / ID from the list of PCODE.

Operating procedure	Operation	Display
<p>① Move the arrow to the PCODE, press [F2](SRCH)</p> <p>② By pressing the following keys, the register number will increase or decrease.</p> <p>[▲] or [▼]: Increasing or decreasing one by one</p> <p>[◀] or [▶]: By ten increasing or Decreasing.</p> <p>*1)</p> <p>Press [F4] (ENT) to confirm.</p>	<p>[F2]</p> <p>[F4]</p>	<div> PT# :F023  PCODE &gt;  Ref.Hr: 0.000m  INPT SRCH MEAS ALL </div> <div> &gt;001: TREE  002: SYG  EDIT --- CLR ENT </div> <div> 011: DKIID  &gt;012: AGE0  013: IOOF  EDIT --- CLR ENT </div> <div> PT# :F023  PCODE &gt;AGE0  Ref.Hr &gt; 0.000m  INPT SRCH MEAS ALL </div>
<p>※1) To edit the PCODE library, press the [F1](EDIT) key.</p> <p>To delete the PCODE registered with shown an arrow, press the [F3] (CLR) key.</p> <p>PCODE can be edited in DATA COLLECT menu 2/2 or MEMORY MANAGER menu 2/3.</p>		


7.8 Data Collect Offset Measurement mode

For these series of total stations, Offset measurement has four measuring methods:

- 1. Angle offset measurement
- 2. Distance offset measurement
- 3. Plane offset measurement
- 4. Column offset measurement

7.8.1 Angle offset measurement

This program is used to measure the point where is difficult to set prism. Place the prism at the same horizontal distance from the instrument as that of point A0 to measure.



When measuring c  
height and prism h  
When measuring c  
only.(Set the prism

Operating procedu

①Press the [F3] (MEAS)  
key.


[F3]

PT# >
PCODE:
Ref.Hr: 0.000m
INPT SRCH MEAS ALL
VH HD NEZ OFST



### 7.8.2 Distance Offset Measurement

The measurement of an object point apart from a prism is possible by inputting offset horizontal distance of front or back/right or left.



When measuring coordinates of ground point A1: set the instrument height and prism height. When measuring A0: set instrument height only.

Make sure the mode is Data Collect.


Operating procedure	Operation	Display
① Press the [F3] (MEAS) key	[F3]	<div>PT# :F003</div> <div>PCODE &gt;0</div> <div>Ref.Hr: 0.000m</div> <div>INPT SRCH MEAS ALL</div> <div>VH HD NEZ OFST</div>
② Press the [F4] (OFST) key.	[F4]	<div>OFFSET</div> <div>F1: ANG. OFFSET</div> <div>F2: DIST. OFFSET</div> <div>F3: PLANE OFFSET</div> <div>F4: COLUMN OFFSET</div>

<p>③Press the [F2] key (DIST OFFSET).</p> <p>④Enter Right or Left distance offset value; press [F4] to confirm.</p> <p>⑤Enter forward distance offset value; press [F4] to confirm.</p> <p>⑥Enter the PT#, PCODE, Ref.Hr. Collimate the prism, select measuring mode as distance or coordinate, and then begin measure distance.</p> <p>⑧Measured data is shown, press [F3] (YES), it'll be back to the previous menu.</p>	[F2]	DISTANCE OFFSET INPUT RorL HD HD:                   m ---    ---    CLR    ENT
	[F4]	DISTANCE OFFSET INPUT RorL HD HD=1_ ---    ---    CLR    ENT
	[F4]	DISTANCE OFFSET INPUT FORWARD HD HD=2_ ---    ---    CLR    ENT
	Collimate prism [F2] Or [F3]	PT#               >F003 PCODE           :M Ref.Hr :       1.000m ---   SD    COORD   ---
		N:       22.000m E:       123.210m Z:       100.000m >OK?    [YES] [NO]
	[F3]	OFFSET F1: ANG. OFFSET F2: DIST. OFFSET F3: PLANE OFFSET F4: COLUMN OFFSET

### 7.8.3 Plane Offset Measurement

Measuring will be taken for the place where direct measuring can not be done, for example distance or coordinate measuring for a edge of a plane.

Three random points (P1, P2, P3) on a plane will be measured at first in the plane offset measurement to determine the measured plane, collimate the measuring point (P0), the instrument calculates and displays coordinate and distance value of cross point between collimation axis and of the plane.



Operating procedure	Operation	Display
① Press the [F3] (MEAS) key	[F3]	<div> PT# :F004  PCODE &gt;0  Ref.Hr: 0.000m  INPT SRCH MEAS ALL </div> <div> VH HD NEZ OFST </div>
② Press the [F4] (OFST) key.	[F4]	<div> OFFSET  F1: ANG. OFFSET  F2: DIST. OFFSET  F3: PLANE OFFSET  F4: COLUMN OFFSET </div>




Operating procedure	Operation	Display
③Press the [F3] key (plane offset).	[F3]	<div>PLANE N001# SD: m MEAS --- --- ---</div>
④Collimate point P1, and press the [F1] (MEAS) key to measure. After measuring, the display will show the second point measurement.	Collimate P1 [F1]	<div>PLANE N002# SD: m MEAS --- --- ---</div>
⑤Collimate point P2, and press the [F1] (MEAS) key to measure.	Collimate P2 [F1]	<div>PLANE N003# SD: m MEAS --- --- ---</div>
⑥Collimate point P3, and press the [F1] (MEAS) key to measure.	Collimate P3 [F1]	<div>PLANE PT# &gt;F004 PCODE: V INPT SRCH --- MEAS</div>
⑦Collimate the point P0 on plane edge.	Collimate P0	<div>VZ: 70° 33' 58" HR: 81° 54' 21" HD: 1.425m VD: 1.285m SD: 1.271m [YES] [NO]</div>
⑧Press the F4 (MEAS) key, the instrument calculates and displays coordinate and distance value of cross point between collimation axis and of the plane.※1) ※2)	[F4]	
⑨Press the [F3] (YES) key to confirm and record, the display returns to the next point number in Plane Offset menu.	[F3]	<div>PLANE PT# &gt;F005 PCODE: V INPT SRCH --- MEAS</div>

- ※1) In case the calculation of plane was not successful by the measured three points, error displays. Start measuring over again from the first point.
- ※2) Error will be displayed when the collimated direction does not cross with the determined plane.

#### 7.8.4 Column Offset Measurement

It is possible to measure circumscription point (P1) of column directly, the distance to the center of the column (P0), coordinate and direction angle can be calculated by measuring circumscription points (P2) and (P3)

The direction angle of the column center is average of circumscription points (P2) and (P3).



Operating procedure	Operation	Display
① Press the [F3] key (MEAS)	[F3]	PT# :F005 PCODE >0 Ref.Hr: 0.000m INPT SRCH MEAS ALL
② Press the [F4](OFST) key	[F4]	VH HD NEZ OFST

<p>③Press the [F4](column offset) key.</p> <p>④Collimate the center of column P1, and press the [F1] (MEAS) key to measure N times.</p> <p>⑤Collimate the left side of the column (P2) and press the [F4] (SET) key.</p> <p>⑥Collimate the right side of the column (P3) and press the [F4] (SET) key.</p> <p>⑦The distance between the instrument and center of the column (P0) will be calculated and shown.</p> <p>⑧Press the [F3] (YES) key to confirm and record.</p>	<p>Collimate P1 [F1]</p> <p>Collimate P2 [F4]</p> <p>Collimate P3 [F4]</p> <p>[F3]</p>	<div>           OFFSET            F1: ANG. OFFSET            F2: DIST. OFFSET            F3: PLANE OFFSET            F4: COLUMN OFFSET         </div> <div>           COLUMN OFFSET            Center            HD:                      m            MEAS     ---     ---     ---         </div> <div>           COLUMN OFFSET            Center            HD*                      1.234m            &lt; Measuring&gt;         </div> <div>           COLUMN OFFSET            Left            HR:     12° 34' 56"            ---     ---     ---     SET         </div> <div>           COLUMN OFFSET            Right            HR:     12° 34' 56"            ---     ---     ---     SET         </div> <div>           COLUMN OFFSET            HR:     12° 34' 56"            HD:                      1.234m            &gt; OK?     [YES]     [NO]         </div> <div>           OFFSET            F1: ANG. OFFSET            F2: DIST. OFFSET            F3: PLANE OFFSET            F4: COLUMN OFFSET         </div>
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 7.9 NEZ Auto Calculation

As measured data is collected, coordinates are calculated and stored for traverse or topo collection. Automatic making out function of coordinate data sets up in CONFIG of data collect. Refer to Section

### 7.10 “Setting Parameter of Data Collect [CONFIG.]”.

As a default, coordinate data calculated will be saved in a file of the same name as the measurement data file. When the coordinate data file of the same name as the measurement data file does not exist, it will be generated automatically. It is possible to change a file for saving coordinate data in the DATA COLLECT Menu 2/2 (F1: SELECT A FILE).

To calculate a coordinate data, it is necessary to add a point number in Data Collect execution. When a coordinate data of the same point number exist already, it can be replaced with the new data by confirming display.

- Coordinates will be calculated using the grid factor. To set the grid factor, see Section 8.6“Setting the GRID FACTOR”

## 7.11 Setting Parameter of Data Collect [CONFIG.]

In this mode, the following settings of data collect mode are possible

### ● Setting Items:

Menu	Selecting Item	Contents
F1:HD/SD	HD/SD	Select the distance measurement mode Horizontal Distance or Slope distance.
F2:MEAS ORDER	N TIMES/S TIMES/REPEAT	Select to set measurement mode for distance measurement.
F3:DATA CONFIRM	YES/NO	It is possible to confirm the result of measuring data before the data is recorded.
F1:COLLECT ORDER	Edit→Meas/ Meas→Edit	Select the procedure of data collection. [EDIT →MEAS]: Measurement is carried out after entering other data. [MEAS→EDIT]: Measurement is carried out before entering other data.
F2:NEZ AUTO.CALC	ON/OFF	It is possible to calculate coordinate value of data collected and store it into coordinate data file in every data collection.

## ● How to Set items

Example Setting: DATA CONFIRM: YES

Operating procedure	Operation	Display
①The instrument in Data Collect mode.		<div>COLLECT 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: FS/SS</div> <div>F4: SELECT A FILE</div>
②Press [▼] to enter collect menu 2/2.	[▼]	<div>COLLECT 2/2</div> <div>F1 PCODE INPUT</div> <div>F2 CONFIG</div>
③Press [F2]to show CONFIG menu.	[F2]	<div>SET ↓</div> <div>F1: HD/SD</div> <div>F2: MEAS ORDER</div> <div>F3: DATA CONFIRM</div> <div>F4: COLLECT ORDER</div>
④Press [F3] (DATA CONFIRM).	[F3]	<div>Data Confirm</div> <div>F1: YES</div> <div>[F2: NO]</div> <div>ENT</div>
⑤ Press [F1](YES) key, then press [F4] key to confirm.	[F1] [F4]	<div>Data Confirm</div> <div>[F1: YES]</div> <div>F2: NO</div> <div>ENT</div>

## 8. Coordinate Layout

Layout mode has two functions which are setting of layout points and setting new points using coordinate data in the internal memory. Also, if the coordinate data is not stored in the internal memory, this can be input from key board. The coordinate data is loaded from PC to the internal memory via RS-232C.

### The coordinate data

The coordinate data is memorized into a file, the memory has three recorded parts, one is for measured data, another is for coordinate data, and the last one is for PCODE data.

For the internal memory, refer to Chapter 10 “Memory Manager Mode”

- 1) When turning off the power, ensure that you are in the main menu screen or angle measurement mode. This ensures completion of the memory access process and avoids possible damage of the stored data.
- 2) It is recommended for safety to charge the battery beforehand and prepared fully charged spare batteries.

### 8.1 Layout procedures

- 1) Selecting a file for layout.
- 2) Input Occ. point.
- 3) Input backsight point or backsight angle.
- 4) Input or pick-up (from internal memory) the coordinate data for layout point. Start layout.

### 8.2 Selecting or creating a coordinate data file

You can execute a Layout from selected coordinate data file.

Here one existing coordinate data file can be selected; also you can input a new file name to create one new file for coordinate layout

Operating procedure	Operation	Display
①Press [MENU] key, the instrument will be in MENU mode.	[MENU]	<div>MENU 1/2 ↓  F1:DATA COLLECT  F2:LAYOUT  F3:MEMORY MGR.  F4:PROGRAMS</div>
②Press [F2] key, to enter file selecting menu.	[F2]	<div>SELECT A C.FILE  FN:   INPT LIST SKIP ENT</div>
③Press [F2] key to display the list of coordinate data file. ※1) ※2)	[F1]	<div>&gt; *1 /C0002  1SV /C0000   TOP LAST SRCH ENT</div>
④Scroll file list by pressing the [▲]or[▼]key and select a file to use.※3)	[ ▼ ]	
⑤Press [F4] key, the file will be selected.	[F3]	<div>*1 /C0002  &gt; 1SV /C0000  S /C0000  TOP LAST SRCH ENT</div>
Instrument enters Layout Menu.		<div>Layout 1/2 ↓  F1: OCC. PT# INPUT  F2: BACKSIGHT  F3: LAYOUT  F4: SELECT A FILE</div>
<p>※1) If you want to input file name directly, press[F1]key to enter.</p> <p>※2) If you input a file name that it is not found in memory, a new coordinate file with input name will be created automatically.</p> <p>※3) When a file has been selected already, mark “*”is indicated on left of current file name.</p> <p>● It is possible to select a file from Layout 1/2, menu in the same way.</p>		



## 8.3 Occupied Point Setting

1) Setting the coordinate data from the internal memory.

Example: Confirm the coordinate data file has been selected already

Operating procedure	Operation	Display
①The instrument be in LAYOUT mode.		<div>Layout 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: LAYOUT</div> <div>F4: SELECT A FILE</div>
②Press [F1] key.	[F1]	<div>OCC. PT</div> <div>PT# :</div>
③Press [F2] key.	[F2]	<div>INPT LIST NEZ ENT</div>
※1)		<div>[WS ]</div>
④Press [▲] or [▼] key to select PT#. ※2) ※3)	[F4]	<div>&gt; 2</div> <div>1</div> <div>VIEW SRCH --- ENT</div>
Press [F4] key to confirm.	[F3]	<div>N 5.620m</div> <div>E 4.210m</div> <div>Z 1.250m</div> <div>&gt;OK? [NO] [YES]</div>
⑤ Press [F4] key to select YES.		
⑥Input Ins.Hi. Range:-999.999~ +999.999m Press [F4] key.	[F4]	<div>INSTRUMENT</div> <div>HEIGHT INPUT</div> <div>Ins.Hi =1.000 m</div> <div>--- --- CLR ENT</div>
※1) Direct input PT#: Press [F1] key and input PT#.		
※2) The selected coordinate data can be viewed by press[F1](VIEW) key.		
※3) The coordinate data can be searched by press[F2](SRCH).		

## 2) Input the point number of occupied point directly

Operating procedure	Operation	Display
①The instrument be in LAYOUT mode.		<div>Layout 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: LAYOUT</div> <div>F4: SELECT A FILE</div>
②Press [F1] key.	[F1]	<div>OCC. PT</div> <div>PT# :</div> <div>INPT LIST NEZ ENT</div>
③Press [F1] key to enter the point number, and press [F4] to confirm.	[F1] Enter PT# [F4]	<div>OCC. PT</div> <div>PT# =F023_</div> <div>ALPH SPC CLR ENT</div>
④The coordinate value will display.		<div>N 5.620m</div> <div>E 4.210m</div> <div>Z 1.250m</div> <div>&gt;OK? [NO] [YES]</div>
⑤ Press [F4] key to select YES.	[F3]	
⑥Input Ins.Hi. Range:-99.999~ +99.999m	Input Inst.H [F4]	<div>INTRUMENT</div> <div>HEIGHT INPUT</div> <div>Ins.Hi=1.5 _</div> <div>--- -- CLR ENT</div>
Press [F4] key to confirm, instrument will back to Layout menu automatically.		<div>Layout 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: LAYOUT</div> <div>F4: SELECT A FILE</div>

## 8.4 Setting Backsight Point

### 1) Setting the coordinate data file from the internal memory

Make sure the instrument displays layout menu

Operating procedure	Operation	Display
① Press [F2] (BACKSIGHT) key to set backsight point.	[F2]	BACKSIGHT PT#  INPT LIST NEAZ ENT
② Press [F2] key to view data file. ※1) ※2)	[F2]	[WS ] > 2 1 VIEW SRCH --- ENT
③ Press [▲] or [▼] key to select PT#. Press [F4] key.	[▼] [F4]	N 1.000m E 2.000m Z 1.100m >OK? [ NO] [ YES]
④ The coordinate value will display. Press [F4] key to select YES. ※3)	[F4]	BACKSIGHT HR:283° 25' 33" >Sight? --- dHD YES NO
⑤ Collimate backsight, press [F3] key and return back the layout menu. ※4)	Collimate backsight [F3]	Layout 1/2 ↓ F1: OCC. PT# INPUT F2: BACKSIGHT F3: LAYOUT F4: SELECT A FILE

※1) Press [F1](VIEW) key the coordinate data values can be displayed.

※2) Press [F2](SRCH) key the coordinate data can be searched by entering PT#.

※3) Press [F4](NO) key return to points list menu.

※4) Press [F2](dHD) to measure the difference between calculated backsight and true backsight

## 2) Direct key input of setting angle.

Make sure the instrument displays layout menu

Operating procedure	Operation	Display
①Press [F2] key.	[F2]	<div>BACKSIGHT</div> <div>PT# :</div> <div>INPT LIST NEAZ ENT</div>
②Press[F3](NEAZ) key.※1)	[F3]	<div>BACKSIGHT</div> <div>N &gt; 0.000m</div> <div>E : 0.000m</div> <div>INPT ---- AZ ENT</div>
③Press [F3] (AZ) key.	[F3]	<div>BACKSIGHT</div> <div>HR:</div>
④Press [F1] key and enter setting angle. 123°16'18" Press [F4] key.	[F1]	<div>INPT ---- PT# ENT</div>
⑤Collimate backsight, press [F3] key and return back the layout menu.	[123.16 18] [F4] Collimate backsight [F3]	<div>BACKSIGHT</div> <div>HR =123.1618</div> <div>--- --- CLR ENT</div> <div>BACKSIGHT</div> <div>HR :123° 16' 18"</div> <div>&gt;Sight? YES NO</div>
※1) With each pressing of [F3] key, switched among PT#, NE (coordinate) and AZ (backsight angle).		

## 8.5 Executing a Layout

The following methods can be selected for executing a layout.

- 1) Recalling points from internal memory by point number.
- 2) Direct key input of coordinate values.

Example setting: recalling point from internal memory

Operating procedure	Operation	Display
①Make sure the displaying is layout menu.		<div>Layout 1/2 ↓</div> <div>F1: OCC. PT# INPUT</div> <div>F2: BACKSIGHT</div> <div>F3: LAYOUT</div> <div>F4: SELECT A FILE</div>
②Press [F3] (LAYOUT) key.	[F3]	<div>LAYOUT</div> <div>PT# :</div> <div>INPT LIST NEZ ENT</div>
③Press [F2] (LIST) key. ※1)	[F2]	<div>[AGEOMA]</div> <div>&gt; 2</div> <div>1</div> <div>VIEW SRCH --- ENT</div>
④Press [▲] or [▼] key to select PT#. Press [F4] key. ※2) ※3)	[F4]	<div>N: 2.615m</div> <div>E: 3.186m</div> <div>Z: 1.268m</div>
⑤Press [F4] (YES) key to confirm the coordinate. ※4)	[F3]	<div>&gt;OK? [NO] [YES]</div>
⑥Input target height Ref.Hr.		<div>REF HT INPUT</div>
⑦Press [F4] key.	[F4]	<div>Ref.Hr=1.75_</div> <div>--- --- CLR ENT</div>
HR: calculated horizontal angle of the layout point		<div>CACULATED</div> <div>HR: 44° 38' 29"</div> <div>HD: 173.464m</div> <div>ANG DIST --- ---</div>
HD: Calculated horizontal distance from the instrument to the layout point		
⑧Collimate the prism, press [F1] (ANG) key.	[F1]	<div>PT# :</div> <div>HR : 44° 38' 29"</div> <div>dHR: 30° 38' 29"</div> <div>DIST --- CORD ---</div>
HR: measured(actual) horizontal angle		

<p>dHR: Horizontal angle to be turned to the layout point=Actual horizontal angle-Calculated horizontal angle.</p> <p>Correct direction when dHR=0°00'00"</p> <p>⑨Press [F1] (DIST) key to measure distance.</p> <p>dHD: Horizontal distance to be moved to the layout point=Actual horizontal distance-Calculated horizontal distance.</p> <p>dZ: Vertical distance to be moved to the layout point=Actual vertical distance-Calculated vertical distance.</p> <p>Press the [ESC] to stop measure.</p> <p>When the display value dHR, dHD and dZ are equal to 0, the layout point is established. ※4) ※5)</p> <p>⑩Press [F3] (ANG) key to</p>	<p>[F1]</p> <p>[ESC]</p>	<div data-bbox="570 513 891 701"> <p>PT#</p> <p>dHR: 346° 08' 20"</p> <p>dHD: -7.810 m</p> <p>dZ : - 0.022 m</p> <p>DIST MODE ANG NEXT</p> </div> <div data-bbox="578 966 899 1157"> <p>PT#</p> <p>dHR: 000° 00' 12"</p> <p>dHD: -0.001 m</p> <p>dZ : - 0.002 m</p> <p>DIST MODE ANG NEXT</p> </div> <div data-bbox="567 1233 897 1389"> <p>PT# :</p> <p>HR : 44° 38' 29"</p> <p>dHR: 30° 38' 29"</p> <p>DIST --- CORD ---</p> </div>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>setting screen, press [F3] (CORD) key again, the coordinate data is shown. Press [F2] mode key to setting the distance measuring mode.</p> <p>③ Press [F4] key to set next layout point.</p>	<p>[F3]</p> <p>[F3]</p>	<div data-bbox="645 200 971 357"> <p>N: 56.287 m</p> <p>E: 986.321 m</p> <p>Z: 123.345 m</p> <p>DIST MODE ANG NEXT</p> </div> <div data-bbox="640 402 960 559"> <p>LAYOUT</p> <p>PT#:</p> <p>INPT LIST NEZ ENT</p> </div>
<p>※1) If you want to input PT# directly, press [F1]key and enter PT#.</p> <p>※2) The coordinate data can be viewed by press [F1]key.</p> <p>※3) The coordinate data can be searched by press [F2]key and enter PT#.</p> <p>※4) As normal, rotating the horizontal circle and make dHR reach 0. Setting the prism as this direction. Make the dHD and dZ reach 0 by distance measured.</p> <p>※5) Cut&amp;Fill displaying function is available. Refer to Chapter 13 “Selecting Mode”.</p> <p>NOTE: After layout, collimate the layout point and measure it's coordinate, and then confirm its accuracy, the measurement mode can be selected.</p>		

## 8.6 Setting the GRID FACTOR

### Calculation Formula

1. Elevation Factor =  $R / (R + \text{ELEV})$

R: The average radius of the earth

ELEV.: The elevation above mean sea level

2. Scale Factor

Scale Factor: Scale Factor at the surveying station

3. Grid Factor

Grid Factor = Elevation Factor  $\times$  Scale Factor

### Distance Calculation

1. Grid Distance

HDg = HD  $\times$  Grid Factor

HDg: Grid distance

HD: Ground distance

2. Ground Distance

HD = HDg / Grid Factor

After the Grid Factor setting is finished, it is used for layout and other coordinate measurement programs.

Operating procedure	Operation	Display
①Displayed the layout menu 2/2.	[F2]	<div> Layout                      2/2 ↑  F1: GRID FACTOR </div>
②Press [F2] key.		<div> GRID FACTOR  =1.000000  &gt; MODIFY?    YES   NO </div>




Operating procedure	Operation	Display
③Press [F3]key.※1)	[F3]	<div> GRID FACTOR  ELEV. =0_ 0 m  SCALE : 1.000000  --- --- CLR ENT </div>
④Enter Elevation. ※2) Press [F4] to confirm.	enter Elevation [F4]	<div> GRID FACTOR  ELEV. = 1000 m  SCALE: 1.000000_  --- --- CLR ENT </div>
⑤Enter Scale Factor. Press [F4]key.※3)	enter Scale Factor [F4]	<div> GRID FACTOR  =1.000685 </div>
⑥Press [F4] key. Grid Factor is displayed, and then returns to Layout menu automatically. ※4)		
※1) Press[F4] key if don't need to change the Grid Factor. ※2) Elevation enter range:-9999m ~ +9999m. ※3) Scale enter range:0.990000 ~ 1.010000. ※4) In Resection program, the Grid Factor need be reset to calculate the error, refer to the procedures from step 2 to step 5 to do that.		

## 9. Application Measurement (Programs)

### 9.1 Remote Elevation Measurement (REM)

Two mode of with prism and without prism can be selected to measure the vertical height from target to prism or ground point, the prism or ground point should be on the vertical line from the target.



1) With prism height (h) input (Example:  $h=1.5\text{m}$ )

Operating procedure	Operation	Display
① Press the [MENU] key to menu mode.	[MENU]	<div> <div>MENU1/2 ↓</div> <div> F1:DATA COLLECT  F2:LAYOUT  F3:MEMORY MGR.  F4:PROGRAMS </div> </div>
② Press the [F1] (PROGRAMS) key.	[F1]	<div> <div>PROGRAM1/2 ↓</div> <div> F1: REM  F2: MLM  F3: Z COORD  F4: AREA </div> </div>

Operating procedure	Operation	Display
③Press the [F1] (REM) key to REM program.	[F1]	<div>REM F1: INPUT R.HT F2: NO R.HT</div>
④Press the [F1] key to select the first mode: INPUT R.HT.	[F1]	<div>REM-1 &lt;STEP-1&gt; Ref.= 0.00_m --- --- CLR ENT</div>
⑤Enter prism height, press [F4] key to confirm.	Enter R.HT [F4]	<div>REM-1 &lt;STEP-2&gt; HD: m MEAS --- --- ---</div>
⑥Collimate prism, press [F1] (MEAS) key to measure distance, the horizontal distance (HD) between instrument and prism will be shown.	Collimate P [F1]	<div>REM-1 &lt;STEP-2&gt; HD: * 21.232 m &lt;Measuring&gt;</div>
⑦The vertical distance (VD) from prism to ground will be decided.	Collimate target	<div>REM-1 VD: 1.5 m  --- HT HD ---</div>
⑧Move telescope, the VD will upgrade in real-time. Collimate target, vertical distance (VD) from target to ground will be decided. ※ 1)		<div>REM-1 VD: 1.602 m  --- HT HD ---</div>
※ 1) Press [F2](HT) to enter the new prism height. Press [F3] (HD) to measuring the horizontal distance again. To return to PROGRAMS Menu, press the [ESC] key.		

## 2) Without prism height input

Operating procedure	Operation	Display
① Press the [MENU] key to menu mode.		<div>PROGRAM 1/2 ↓</div> <div>F1: REM</div> <div>F2: MLM</div> <div>F3: Z COORD</div> <div>F4: AREA</div>
② Press the [F1] (REM) key.	[F1]	<div>REM</div> <div>F1: INPUT R.HT</div> <div>F2: NO R.HT</div>
③ Press the [F2] (NO R.HT) key.	[F2]	
④ Collimate prism Press the [F1] (MEAS) key, measuring starts, horizontal distance (HD) between instrument and prism will be decided.	Collimate P [F1]	<div>REM-2</div> <div>&lt;STEP-1&gt;</div> <div>HD: m</div> <div>MEAS --- ---</div>
		<div>REM-1</div> <div>&lt;STEP-1&gt;</div> <div>HD: * 6.888 m</div> <div>&lt;Measuring&gt;</div>
⑤ Vertical angle (VZ) will be shown	[F4]	<div>REM-2</div> <div>&lt;STEP-2&gt;</div> <div>VZ: 6° 30' 25 "</div> <div>--- --- SET</div>
⑥ Press the [F4] (SET) key. The prism position will be decided.		
⑦ Collimate ground point G. The position of point G will be decided. *1	Collimate G [F4]	<div>REM-2</div> <div>VD: 0.000m</div> <div>--- VZ HD ---</div>
⑧ Collimate target K. Vertical distance (VD) will be shown. *2	Collimate K	<div>REM-2</div> <div>VD: 6.580m</div> <div>--- VZ HD ---</div>

\*1) To return to procedure 4, press the [F3](HD) key.

To return to procedure 5, press the [F2](VZ) key.

\*2) To return to PROGRAMS Menu, press the [ESC] key.


## 9.2 Missing Line Measurement (MLM)

### 9.2.1 Missing Line Measurement


Measurement for horizontal distance (dHD), slope distance (dSD), elevation (dVD) between two targets. MLM has two modes:

1. MLM-1 (A-B, A-C): Measurement is A-B, A-C, A-D.....

2. MLM-2 (A-B, B-C): Measurement is A-B, B-C, C-D.....



MLM-1



MLM-2

[Example]1. MLM-1 (A-B, A-C)

Procedure of MLM-2 (A-B, B-C) mode same as MLM-1 mode

Operating procedure	Operation	Display
① Press the [MENU] key to menu mode.		PROGRAM 1/2 ↓ F1: REM F2: MLM F3: Z COORD F4: AREA
② Press the [F2] (MLM) key.	[F2]	MLM F1: USE FILE F2: DON' T USE
③ Press the [F1] or [F2] key to select using coordinate	[F2]	

<p>file. [Example:F2 : DON'T USE] ④ Press the [F1] or [F2] key to select using GRID FACTOR. [Example:F2 :Not Use] ⑤ Press the [F1] key to select the first measure mode: MLM-1 A-B, A-C. ⑥ Collimate A, press the [F1](MEAS) key to measure distance, ※ 1 )  ⑦ Horizontal distance will display.  ⑧ Collimate B, press the [F1] (MEAS) key to measure distance  ⑨ Horizontal distance (dHD), relative elevation (dVD) and slope distance (dSD) between A and B can be shown.</p>	<p>[F2]</p> <p>Collimate A [F1]</p> <p>Collimate B [F1]</p>	<div data-bbox="555 130 876 290"> <p>GRID FACTOR F1:Use F2:Not Use</p> </div> <div data-bbox="555 330 876 486"> <p>MLM F1:MLM-1 A-B ,A-C F2:MLM-2 A-B,B-C</p> </div> <div data-bbox="555 506 876 664"> <p>MLM-1(A-B, A-C) &lt;STEP-1&gt; HD: m MEAS RHT COOR ---</p> </div> <div data-bbox="555 676 876 835"> <p>MLM-1(A-B, A-C) &lt;STEP-1&gt; HD:* 6.688m &lt;Measuring&gt;</p> </div> <div data-bbox="555 842 876 1001"> <p>MLM-1(A-B, A-C) &lt;STEP-2&gt; HD: m MEAS RHT COOR</p> </div> <div data-bbox="555 1009 876 1167"> <p>MLM-1(A-B, A-C) &lt;STEP-2&gt; HD: * 2.380m &lt;Measuring&gt;</p> </div> <div data-bbox="555 1167 876 1326"> <p>MLM-1(A-B, A-C) dHD: 5.726m dVD: 1.722m dSD: 15.890m --- --- COOR ---</p> </div>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



## 9.2.2 USE FILE and GRID FACTOR

Operating procedure	Operation	Display
① Make sure the display is in [PROGRAMS] mode.		<div>PROGRAM 1/2 ↓</div> <div>F1: REM</div> <div>F2: MLM</div> <div>F3: Z COORD</div> <div>F4: AREA</div>
② Press the [F2] (MLM) key.	[F2]	<div>MLM</div> <div>F1:USE FILE</div> <div>F2:DON'T USE</div>
③ Press [F1](USE FILE) key	[F1]	<div>SELECT A C.FILE</div> <div>FN:1SV</div> <div>INPUT LIST --- ENT</div>
④ Select a coordinate file.		
⑤ Press [F1] (F1:USE) to confirm.	[F4]	<div>GRID FACTOR</div> <div>F1: USE</div> <div>F2: Not Use</div>
⑥ Press [F3] (YES) to confirm the Grid Factor.	[F3]	<div>GRID FACTOR</div> <div>=1.0000000</div> <div>&gt;OK? [YES][NO]</div>
⑦ Repeat 9.2.1 step ④ - ⑩		<div>MLM</div> <div>F1:MLM-1 A-B ,A-C</div> <div>F2:MLM-2 A-B,B-C</div>



### 9.2.3 Use coordinate for MLM program

It is possible to input coordinate value directly or calculate from coordinate data file

Operating procedure	Operation	Display
<p>To use coordinate data file, select “USE FILE” in step ③ of chapter 9.2.1.</p> <p>① Press the [F3](COOR) key.</p> <p>Coordinate direct key input display will be shown.</p>	[F3]	<div>MLM-1(A-B, A-C)</div> <div>&lt;STEP-1&gt;</div> <div>HD: m</div> <div>MEAS RHT COOR ---</div>
<p>③ Press the [F3](PT#) key to use coordinate data file.</p> <p>Point number input display will be shown.</p> <p>Input the point number PT# or select coordinate in LIST.</p>	[F3] Input coordinate or PT#	<div>MLM-1(A-B, A-C)</div> <div>N&gt; 0.000m</div> <div>E: 0.000m</div> <div>Z: 0.000m</div> <div>INPT --- PT ENT</div>
<p>④ Pressing the [F3](HD) key, the display will return to next point setting menu..</p>	[F4]  [F3]	<div>MLM-1 (A-B, A-C)</div> <div>PT#:</div> <div>INPT LIST HD ENT</div> <div>MLM-1(A-B, A-C)</div> <div>&lt;STEP-2&gt;</div> <div>HD: m</div> <div>MEAS RHT COOR</div>

### 9.3 Setting Z Coordinate of Occupied Point

Input occupied point coordinate data, with known point actual measuring data, Z coordinate of occupied point is calculated and reset again. Known point data and coordinate data can recalled from the coordinate data file.

1) Setting coordinate data file (if you don't recall data from memory, please ignore this operation step)

Operating procedure	Operation	Display
①Display PROGRAMS menu on page 1.		<div>PROGRAM 1/2 ↓</div> <div>F1: REM</div> <div>F2: MLM</div> <div>F3: Z COORD</div> <div>F4: AREA</div>
②Press the [F3] (Z COORD) key	[F3]	<div>Z COORD. SETTING</div> <div>F1: USE FILE</div> <div>F2: DON'T USE</div>
③Press the [F1] (USE FILE) key.	[F1]	<div>SELECT A C.FILE</div> <div>FN:</div> <div>INPT LIST --- ENT</div>
④Press the [F2] (LIST) key, the list of coordinate data files are shown.※1)	[F2]	<div>&gt;&amp;1 /C0002</div> <div>1SV /C0000</div> <div>TOP LAST SRCH ENT</div>
⑤press [▲] or [▼] keys, the cursor will move up or down one by one, select a file.※2)	[▼]	<div>&amp;1 /C0002</div> <div>&gt; 1SV /C0000</div> <div>TOP LAST SRCH ENT</div>

⑥Press the [F4] key to confirm.	[F4]	<div> Z COORD. SETTING  F1: OCC. PT INPUT  F2: REF. MEAS </div>
※1) Press the [F1](INPT) key to enter file name directly. ※2) Press the [F3](SRCH) key to scan the coordinate data in the selected file		

## 2) Setting the Coordinate of occupied point

Operating procedure	Operation	Display
①Make sure the displaying is in Z Coordinate mode		<div> Z COORD. SETTING  F1: OCC. PT INPUT  F2: REF. MEAS </div>
②Press the [F1] key (OCC. PT INPUT)	[F1]	<div> OCC.PT  PT#: </div>
③Press the [F2](LIST) key to display coordinates list.※1) ※2)	[F2]	<div> INPT   LIST   NEZ   ENT </div>
④Press [▲] or [▼] keys, the cursor will move up or down one by one, select a point. Press the [F4] key to confirm※3)	[F4]	<div> <div>&gt;2 1</div> <div>[S       ]</div> <div>VIEW   SRCH   ---   ENT</div> </div>
⑤The coordinate value will be shown, press the [F4] (YES) key to confirm.	[F3]	<div> N:        1002.362m  E:        566.231m  Z:        100.002m  &gt;OK?        NO   YES </div>
⑥Input the instrument		<div> INSTRUMENT  HEIGHT INPUT  Ins.HT=1.000 m  ---        ---       CLR   ENT </div>

height and press the [F4] to confirm.	Enter I.HT [F4]	<div> Z COORD. SETTING  F1: OCC. PT INPUT  F2: REF. MEAS </div>
※1) Press the [F1] (INPT) key to input point number directly. ※2) Press the [F3] (NEZ) key to input coordinate data directly. ※3) Press the [F1] (VIEW) key to scan the coordinate data in the selected file.		

### 3) Z Coordinate Calculation from Known Point Measuring Data

Example: Using coordinate data file

Operating procedure	Operation	Display
①The display return to Z Coordinate program after selected the coordinate for occupied point.		<div> Z COORD. SETTING  F1: OCC. PT INPUT  F2: REF. MEAS </div>
②Press the [F2] key. (REF. MEAS)	[F2]	<div> N001#  PT#:  INPT LIST NEZ ENT </div>
③Press [F2] (LIST) key to open the data list, select a point, press [F3] (YES) to confirm.	[F2] Select PT# [F3]	<div> N: 1002.362m  E: 566.231m  Z: 100.002m  &gt;OK? NO YES </div>
④Press [F1](INPT) to input prism height R.HT Press [F4] to confirm.	[F1] Input R.HT [F4]	<div> REF HT INPUT  Ref.Hr=1.500_ m  --- --- CLR ENT </div>

<p>⑤ Collimate prism Press the [F3] (YES) key to start measure distance.</p> <p>⑥ Press the [F4] (CALC) key, the result will be shown. ※1) Z:Z coordinate dZ: standard error</p> <p>⑦ Press the [F4] (SET) key, the result will be set as the Z coordinate of occupied point. Backsight point measuring screen will be shown.※2)</p> <p>⑧ If press the [F3](YES) key, azimuth angle will be set, the display returns to Z coordinate program mode</p>	<p>Collimate P</p> <p>[F3]</p> <p>[F4]</p> <p>[F4]</p> <p>[F3]</p>	<div data-bbox="617 135 937 345"> <p>REF HT INPUT</p> <p>Ref. 1.5m</p> <p>&gt; SIGHT? YES NO</p> <p>&gt; Measuring.....</p> </div> <div data-bbox="617 362 937 517"> <p>HR: 142° 23' 59"</p> <p>HD: 15.8m</p> <p>VD: 10.3m</p> <p>NEW --- --- CALC</p> </div> <div data-bbox="617 528 937 684"> <p>Z COORD. SETTING</p> <p>Z 12.345m</p> <p>dZ 0.000m</p> <p>--- --- BS SET</p> </div> <div data-bbox="617 694 937 850"> <p>BACK SIGHT</p> <p>HR: 180° 00' 00"</p> <p>&gt; Sight? YES NO</p> </div> <div data-bbox="617 860 937 1020"> <p>PROGRAM 1/2 ↓</p> <p>F1: REM</p> <p>F2: MLM</p> <p>F3: Z COORD</p> <p>F4: AREA</p> </div>
<p>※1) Press the [F1](NEW) key to measure more points to improve precision, repeat the steps from ② to ⑤ .</p> <p>※2) Pressing the [F3] key, the display will be changed alternately.</p>		

## 9.4 Area Measurement

This mode calculates the area of a closed figure.

There are two area calculation methods as follows.

1) Area Calculation from Coordinate data file

2) Area Calculation from Measured data

- Area is not calculated correctly if enclosed lines cross each other.
- It is impossible to calculate what a mix of coordinate file data and measured data.
- If the coordinate data file does not exist, the area calculation from measured data is done automatically.
- The numbers of points used to calculate are not limited.

### 9.4.1 Area Calculation from Coordinate Data File

Operating procedure	Operation	Display
①Enter PROGRAMS menu.		<div>PROGRAM 1/2 ↓</div> <div>F1: REM</div> <div>F2: MLM</div> <div>F3: Z COORD</div> <div>F4: AREA</div>
②Press the [F4] (AREA) key.	[F1]	<div>AREA</div> <div>F1:KNOWN DATA</div> <div>F2:MEASURE</div>
③Press [F1] (KNOWN DATA) key	[F1]	<div>SELECT A C.FILE</div> <div>FN:FY_</div>
④ Press the [F1] (INPUT) key and enter the file name.	[F1]	<div>INPT LIST --- ENT</div>
Initial display will be shown. The top of the file data is set as the first point of area automatically.	Enter the File name [F4]	

<p>⑤ Press the [F4](NEXT) key. ※1) , ※2) The top of the file data (F001) will be set and the second point number will be shown. ⑥ Repeat pressing the [F4] (NEXT) key to set required number of points.</p> <p>When 3 or more points are set, the area surrounded by the points is calculated and the result will be shown. ※3)</p>	[F4]	<div data-bbox="638 152 959 308"> <p>AREA 0000 m.sq NEXT PT:F001 PT CALL UNIT NEXT</p> </div> <div data-bbox="638 330 959 486"> <p>AREA 0001 m.sq NEXT PT:F002 PT CALL UNIT NEXT</p> </div> <div data-bbox="638 523 959 679"> <p>AREA 0003 25.650 m.sq NEXT PT:F004 PT CALL UNIT NEXT</p> </div>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

※1) To set specify point, press the [F1](PT) key.

※2) To show the list of the coordinate data in the file, press the [F2](CALL) key.

※3) Every time press the [F3](UNIT) key to switch area unit.

#### 9.4.2 Area Calculation from measured data


Operating procedure	Operation	Display
<p>① Enter PROGRAMS menu.</p> <p>② Press the [F4](AREA) key.</p>	[F1]	<div data-bbox="625 1035 947 1191"> <p>PROGRAM 1/2 ↓ F1: REM F2: MLM F3: Z COORD F4: AREA</p> </div> <div data-bbox="625 1213 947 1369"> <p>AREA F1: KNOWN DATA F2: MEASURE</p> </div>

<p>③ Press [F2] (MEASURE) key.</p> <p>④ Press the [F1] or [F2] key to select using GRID FACTOR. [Example:F2 : DON'T USE]</p> <p>⑤ Collimate a prism and press the [F1] (MEAS) key. Measuring starts.</p> <p>⑥ Collimate next point and press the [F1] (MEAS) key.</p> <p>⑦ When 3 or more points are measured, the area surrounded by the points is calculated and the result will be shown. ※1)</p>	<p>[F1]</p> <p>[F2]</p> <p>[F4]</p> <p>[F1]</p>	<div data-bbox="581 130 902 287"> <p>AREA</p> <p>F1:USE GRID FACTOR</p> <p>F2:NOT USE</p> </div> <div data-bbox="581 308 902 465"> <p>AREA 0000</p> <p>m.sq</p> <p>MEAS --- UNIT AIM</p> </div> <div data-bbox="581 501 902 658"> <p>AREA 0001</p> <p>N: 154.894m</p> <p>E: 45.685m</p> <p>Z: 10.588m</p> <p>&lt;Measuring&gt;</p> </div> <div data-bbox="581 694 902 851"> <p>AREA 0002</p> <p>m.sq</p> <p>MEAS --- UNIT AIM</p> </div> <div data-bbox="581 952 902 1110"> <p>AREA 0003</p> <p>56.741 m.sq</p> <p>MEAS --- UNIT AIM</p> </div>
<p>※1) Every time press the [F3](UNIT) key to switch area unit.</p>		



## 9.5 Point to Line

This mode is used to obtain the relative coordinate data from the coordinate system: origin point A (0, 0, 0) and the line AB as N axis. Place the 2 prisms at the points A and B on the line, and place the instrument at unknown point C. After measuring the 2 Prisms, the coordinate data and the direction angle of the instrument will be calculated and restored.



Operating procedure	Operation	Display
① Make sure the displaying is in Program menu on page 2.	[F2]	<div>PROGRAM 2/2↑</div> <div>F1: POINT TO LINE</div> <div>F2: NEW POINT</div> <div>F3: ROAD</div>
② Press the [F1] (POINT TO LINE) key.	Enter	
③ Enter instrument height	INS.HT	
Press the [F4] key to confirm.	[F4]	<div>INSTRUMENT</div> <div>HEIGHT INPUT</div> <div>Ins.Hi= 1.750_ m</div> <div>--- --- CLR ENT</div>

<p>④Enter the reflector height of Point A, [F4] (ENT) to confirm.</p> <p>⑤Collimate Point A(P1), press the [F3] to measure.</p> <p>⑥Enter reflector height of point B. Press the [F4] key to confirm</p> <p>⑦Collimate Point B (P2), press the [F3] to measure.</p> <p>⑧The measured results will be shown. The coordinate data and direction angle of the instrument are calculated and restored. The result (the distance between A and B) will be displayed.</p>	<p>Enter Ref.Hr [F4]</p> <p>[F3]</p> <p>Enter R.HT [F4]</p> <p>Collima te A [F3]</p>	<div data-bbox="578 139 899 295"> <p>REF HT INPUT</p> <p>Ref..Hr            0.000m</p> <p>---    ---    CLR    ENT</p> </div> <div data-bbox="578 314 899 470"> <p>POINT TO LINE</p> <p>MEAS. P1</p> <p>HD:                            m</p> <p>&gt;SIGHT?            YES    NO</p> </div> <div data-bbox="578 488 899 644"> <p>POINT TO LINE</p> <p>MEAS. P1</p> <p>HD:*            15.632            m</p> <p>&lt;Measuring&gt;</p> </div> <div data-bbox="578 663 899 819"> <p>REF HT INPUT</p> <p>Ref.Hr=2.500_            m</p> <p>---    ---    CLR    ENT</p> </div> <div data-bbox="578 836 899 992"> <p>POINT TO LINE</p> <p>MEAS. P2</p> <p>HD:                            m</p> <p>&gt;SIGHT?            YES    NO</p> </div> <div data-bbox="578 1010 899 1166"> <p>POINT TO LINE</p> <p>MEAS. P1</p> <p>HD*                            78.840 m</p> <p>&lt; Measuring&gt;</p> </div> <div data-bbox="578 1184 899 1221"> <p>&lt; Complete&gt;</p> </div> <div data-bbox="578 1239 899 1393"> <p>DIST. (P1-P2)</p> <p>dHD:            8.080m</p> <p>dVD:            0.080m</p> <p>DSD:            0.080m</p> <p>NEZ    S.CO    ---    ---</p> </div>
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>⑨ Press the [F2] (S.CO) key, the new coordinate of occupied point will be shown. The result will be shown. Press F2[P1P2] to return to show the distance between A and B.</p>	[F4]	<div style="border: 1px solid black; padding: 10px;"> STN  N:                0.000m  E:                0.000m  Z:                0.000m   COOR     P1P2 </div>
<p>⑩ Press the [F1] (NEZ) key to measure other points.</p>	[F1]	<div style="border: 1px solid black; padding: 10px;"> N:                8.000m  E:                1.000m  Z:                0.080m  EXIT     ---     HT   MEAS </div>
<p>⑪ Collimate a prism and press the [F4] (MEAS) to start measure.</p>	[F4]	

## 9.6 Setting a new point

New point is required for example when a layout point cannot be sighted from existing control point.

### 9.6.1 Side short method

Set up the instrument at a known point, and measure the coordinate of the new points by the side short method.

Operating procedure	Operation	Display
<p>① Make sure the displaying is in program menu on page2.</p> <p>② Press[F2](NEW POINT) key.</p> <p>③Press [F1](SIDE SHORT) key.</p> <p>④ Press [F2](LIST) key to display the list of coordinate date file.※1)</p> <p>⑤Scroll file list by pressing [▲] key or [▼]key and select a file to use.※2)</p>	[F3]	<div>PROGRAM 2/2↑</div> <div>F1: POINT TO LINE</div> <div>F2: NEW POINT</div> <div>F3: ROAD</div>
	[F1]	<div>NEW POINT</div> <div>F1: SIDE SHORT</div> <div>F2: RESECTION</div>
	[F2]	<div>SELECT A FILE</div> <div>FN:</div> <div>INPT LIST --- ENT</div>
	[▲] or [▼]	<div>&gt;&amp;1 /C0002</div> <div>1SV /C0000</div> <div>TOP LAST SRCH ENT</div>
		<div>&amp;1 /C0002</div> <div>&gt;1SV /C0140</div> <div>S /C0000</div> <div>TOP LAST SRCH ENT</div>

<p>⑥ Press the[F4](ENT) key. The file will be set.</p> <p>⑦ Press the[F1] key , and enter the new point name PT#. Press the [F4] key.</p> <p>⑧ Enter R.HT in the same way.</p> <p>⑨ Collimate the new point, and press the [F3](YES) key to start measure distance.</p> <p>⑩ Press [F3](YES) key. The coordinate value is stored into COORD.DATA.file The input menu for next new point is displayed. PT# is automatically incremented</p>	<p>[F4]</p> <p>[F1] Enter</p> <p>PT# [F4]</p> <p>Enter</p> <p>Ref.Hr [F4]</p> <p>[F3]</p> <p>[F3]</p>	<div data-bbox="643 127 964 283"> <p>SIDE SHOT PT#=F125_</p> <p>NUM SPC CLR ENT</p> </div> <div data-bbox="643 298 964 454"> <p>REF HT INPUT</p> <p>Ref.Hr 0.000 m --- --- CLR ENT</p> </div> <div data-bbox="643 468 964 624"> <p>REFLECTOR HEIGHT INPUT</p> <p>Ref. 1.000 m &gt;Sight? YES NO</p> </div> <div data-bbox="643 639 964 795"> <p>HR: 12° 34' 56"</p> <p>HD* &lt; m VD: m &gt;Measuring...</p> </div> <div data-bbox="643 810 964 847"> <p>&lt; Complete &gt;</p> </div> <div data-bbox="643 862 964 1018"> <p>N: 56.287m E: 986.321 m Z: 123.345 m &gt;REC? [YES] [NO]</p> </div> <div data-bbox="643 1032 964 1188"> <p>SIDE SHOT PT#: F126</p> <p>INPT SCRH --- ENT</p> </div>
<p>※1) Press [F1](INPT) key and enter a file name.</p> <p>※2) The coordinate data can be searched by press [F3] (SRCH) key.</p>		

### 9.6.2 Resection method


Set up the instrument at a new point, and calculate the coordinate of the new point using the coordinate data of up to five known points and the measurements made to these points.

By following observation, resection is possible:

\*Resection by distance measurement: 2 or more known points must be measured.

\* Resection by angle measurement only: 3 or more points must be measured

NOTE: the new point can not be on the circum circle formed by the known points; otherwise the coordinate of new point is not correct.



Operating procedure	Operation	Display
①Make sure the displaying is in Program menu on page2.	[F2]	<div>PROGRAM 2/2↑</div> <div>F1: POINT TO LINE</div> <div>F2: NEW POINT</div> <div>F3: ROAD</div>
② Press [F2](NEW POINT) key.		<div>NEW POINT</div> <div>F1: SIDE SHORT</div> <div>F2: RESECTION</div>
③Press [F2] (RESECTION)		

<p>key.</p> <p>④ Select a coordinate file for known points.</p> <p>⑤ Enter the new point number. Press[F4] key. ※1</p> <p>⑥ Enter the instrument height. Press [F4] key.</p> <p>⑦ Press[F1 (INPT)]key and enter the known point 1. ※2</p> <p>⑧ Press F4(YES) to confirm the coordinate for point 1.</p> <p>⑨ Enter reflector height. Press [F4] key.</p> <p>⑩ Collimate the first known point 1, and press[F3] or [F4]key to select measuring mode. Measuring starts.</p> <p>(11) The second known point B is waiting to confirm, entering display will be shown.</p>	<p>[F2]</p> <p>PT# [F4] [F4]</p> <p>INS.HT [F4]</p> <p>[F1] PT#</p> <p>[F3]</p> <p>R. HT [F4]</p>	<div>SKLECT A C.FILE FN=AGEOMA_  ALPH SPC CLR ENT</div> <div>NEW POINT PT#:45  INPT SRCH SKIP ENT</div> <div>INSTRUMENT HEIGHT INPUT Ins.Hi=1.500_ m --- --- CLR ENT</div> <div>N001# PT#  INPT LIST NEZ ENT</div> <div>N: 99.925m E: 56.369m Z: 9.563m REC? [NO] [YES]</div> <div>REF HT INPUT  Ref.Hr=1.500_ m --- --- CLR ENT</div> <div>REF HT INPUT  Ref.Hr=1.500_ m &gt;SIGHT? ANG DIST</div>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>(12) Same as procedure ⑤ - ⑩ proceed to the second known point 2.</p> <p>When two points have been measured, the RESIDUAL ERROR will be calculated.※3)</p> <p>(13)Select GRID FACTOR for calculation of RESIDUAL ERROR by pressing [F1] or [F2] key. ※3)</p> <p>Example: [F1]</p> <p>(14)Press the [F1](NEXT) key to measure other points.</p> <p>Maximum five points can be measured.</p> <p>(15) Same as procedure ⑤-⑩ proceed to the known point 3.</p> <p>(16)The measured value is displayed. Press the[F4](CALC) key. Standard error will be shown.</p> <p>(17)Press the [F2](NP) key.</p> <p>Standard errors of each coordinate will be shown.</p> <p>The display will be changed alternately by pressing [F2] key.</p> <p>(18) Press the [F4](NEZ) key.</p> <p>Coordinate data of the new point will be shown.</p>		<div data-bbox="593 142 910 301"> N002# PT#  INPT LIST NEZ ENT </div> <div data-bbox="593 365 910 523"> SET GRID FACTOR F1:USE LAST DATA F2:CALC MEASDATA </div> <div data-bbox="593 543 910 701"> RESIDUAL ERROR dHD= 0.002m dZ = 0.003m NEXT --- G.F. CALC </div> <div data-bbox="593 721 910 880"> HR: 1° 23' 45" HD: 1.234 m VD: 0.001 m NEXT --- --- CALC </div> <div data-bbox="593 899 910 1058"> Standard Dev =2.01sec.  --- NP --- NEZ </div> <div data-bbox="593 1077 910 1236"> SD(n) = 1.234m SD(e) = 0.001m SD(z) = 0.000m -- NP --- NEZ </div> <div data-bbox="593 1255 910 1396"> N: 1.234m E: 0.001m Z: 0.000m &gt;REC? [YES] [NO] </div>
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------





be used for horizontal curve layout. Normally one road is constituted by several elements, such as line, circle curve or Spline.

### 9.7.1 Input Element

Operating procedure	Operation	Display
<p>①Make sure the displaying is in Program menu on page2.</p> <p>②Press [F3](ROAD) key.</p> <p>③Press [F1] (Input Element) key.</p> <p>④ Press [F1] (Start Point) key to enter coordinates of first point.</p> <p>⑤Enter the pile number and space distance, then press F4 to confirm. ※1)</p> <p>⑥It will be back the previous</p>	[F3]	PROGRAM 2/2↑ F1: POINT TO LINE F2: NEW POINT F3: ROAD
		ROAD F1: Input Element F2: Road SetOut F3: Road Initialize
	[F1]	Input Element F1: Start Point F2: Horizontal Curve
	[F1]	Start Point N=0.000_ E: 0.000m Pile 0.000m Spac 100.000m CLR ENT
	[F4]	
		Start Point N: 123.000m_ E: 456.000m Pile=1_ Spac 100.000m CLR ENT

<p>page, press F2(Horizontal Curve) to input element of curve.</p> <p>⑦Press F1(Road data Input) key.</p> <p>⑧Press F1(Line).</p> <p>⑨Enter the length and azimuth of line, then press F4 to confirm, it'll be back the previous menu.</p> <p>⑩ Press F2(Circle), enter the radius and length of circle, then press F4 to confirm.</p> <p>(11)Press F1 or F2 to select the direction of circle, after that press F4 to confirm, it'll be back the previous menu.</p>	<p>[F2]</p> <p>[F1]</p> <p>[F1]</p> <p>[F4]</p> <p>[F2]</p> <p>[F4]</p> <p>[F1]</p> <p>or</p> <p>[F2]</p> <p>[F4]</p>	<div data-bbox="648 135 970 295"> <p>Input Element F1: Start Point F2: Horizontal Curve</p> </div> <div data-bbox="648 351 970 511"> <p>Horizontal Curve F1: Road data Input F2: Road data View</p> </div> <div data-bbox="648 575 970 736"> <p>F1: Line F2:Circle F3:Spiral F4: Cross</p> </div> <div data-bbox="648 820 970 980"> <p>Line 1</p> <p>L=0.000_ m AZ: 0° 00' 00"</p> <p>CLR ENT</p> </div> <div data-bbox="648 1015 970 1175"> <p>Circle 2</p> <p>R=0.000_ m L: 0.000 m Turn : LEFT</p> <p>CLR ENT</p> </div> <div data-bbox="648 1202 970 1362"> <p>Circle 2</p> <p>R: 35.000 m L: 16.000 m Turn : LEFT LEFT RIGH --- ENT</p> </div>
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>(12) Press F3(Spiral), enter the radius and length of spiral, then press F4 to confirm.</p> <p>(13) Separately press F1 and F2 to select the turn and direction of spiral, after that press F4 to confirm, it'll be back the previous menu.</p> <p>(14) Press the [F1](NEXT) key to measure other points. Maximum five points can be measured.</p> <p>(15) Input the radius and lengths of incoming spiral and outcoming spiral, then press F4 to confirm. If no need to input, directly press F3 to skip.</p>	<p>[F3] [F4]</p> <p>[F1] or [F2] [F4]</p> <p>[F4] [F4]</p>	<div data-bbox="591 160 909 316"> Spiral 3  R: 400.000 m  L: 16.000 m  Turn : LEFT  Dire: In  CLR ENT </div> <div data-bbox="591 424 909 580"> Spiral 3  R: 400.000 m  L: 16.000 m  Turn : RIGHT  Dire: OUT  IN OUT --- ENT </div> <div data-bbox="591 743 909 899"> Cross 4  N: 123.456 m  E=654.321_ m  CLR ENT </div> <div data-bbox="591 1003 909 1159"> R: 30.000 m  L1: 10.000 m  L2= 8.000_ m  CLR ENT </div>
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------





### 9.7.2 Road Setout

Recall the input element to carry through road calculation and setout.

Operating procedure	Operation	Display
① Press [F2](ROAD SetOut) key.  ② Press [F1](OCC.PT# INPUT) key.  ③ Set up the station by using coordinate data or road data  ④ Press [F1](COORD.DATA) to select coordinate file for calling coordinate to set up the station. ※1)  ⑤ Press [F2](Road.Data) to use the defined road for calculation, input the pile to calculate the road data that can be used as the occupied point and backsight point. Press F4 to confirm.	[F2]	ROAD F1: Input Element F2: Road SetOut F3: Road Initialize
	[F1]	Road SetOut F1: OCC.PT# INPUT F2: Road SetOut
		OCC.PT# INPUT F1:COORD.DATA F2: Road Data
	[F1]	SELECT A C.FILE FN:S  INPT LIST --- ENT
	[F2]	OCC.PT Pile=0.000_
	[F4]	CLR ENT

<p>⑥ Press F1(LEFT) or F2(RIGH) to select if the station is set on the left pile or the right pile, if just set on the middle pile, press F4 to confirm directly</p> <p>⑦ After the pile distance entry, press F4 to confirm ※2)</p> <p>⑧ It will calculate the coordinate of the occupied point, press F4 to confirm.</p> <p>⑨Enter the backsight point pile and press F4 to confirm.</p>	<p>[F1] or [F2]</p> <p>[F4]</p> <p>[F4]</p> <p>[F4]</p> <p>[F4]</p>	<div data-bbox="593 152 912 310"> Pile: 55.000  &gt;Middle  LEFT RIGH --- ENT </div> <div data-bbox="593 486 912 644"> Pile: 55.000  LEFT=7.000_  CLR ENT </div> <div data-bbox="593 719 912 877"> Pile: 55.000  N: 30.000m  E: 20.000m  ENT </div> <div data-bbox="593 936 912 1093"> BACKSIGHT  Pile=56.000_  CLR ENT </div>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



<p>⑩Press F1(LEFT) or F2(RIGH) to select if the backsight point is set on the left pile or the right pile, if just set on the middle pile, press F4 to confirm directly</p> <p>(11)After the pile distance entry, press F4 to confirm※2)</p> <p>(12)It will calculate the coordinate of the backsight point, press F4 to confirm.</p> <p>.</p>	<p>[F1] or [F2]</p> <p>[F4]</p> <p>[F4]</p> <p>[F4]</p>	<div data-bbox="647 154 966 310"> Pile: 56.000  &gt;Middle  LEFT RIGH --- ENT </div> <div data-bbox="647 583 966 739"> Pile: 56.000  RIGH=8.000_  CLR ENT </div> <div data-bbox="647 850 966 1006"> Pile: 56.000  N: 40.000m  E: 50.000m  ENT </div>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>(13) Turn the instrument and aim at the backsight point at face left, press F3 to confirm, it will be back to the previous menu.</p>	[F3]	<div data-bbox="591 142 913 298"> <p>BACKSIGHT</p> <p>HR: 123° ' 1618"</p> <p>&gt;Sight? YES NO</p> </div>
<p>(14) Press ESC to return the previous menu and press F2(Road SetOut).</p>	[ESC] [F2]	<div data-bbox="591 424 913 580"> <p>Road SetOut</p> <p>F1: OCC.PT# INPUT</p> <p>F2: Road SetOut</p> </div>
<p>(15) Input the required pile and press F4 to confirm</p>	[F4]	<div data-bbox="591 639 913 795"> <p>Road SetOut</p> <p>Pile=56.000_</p> <p>CLR ENT</p> </div>
<p>(16) Press F1(LEFT) or F2(RIGH) to select the left pile or the right pile for setout, if just set out the middle pile, press F4 to confirm directly</p>	[F1] or [F2]  [F4]	<div data-bbox="591 862 913 1018"> <p>Pile: 56.000</p> <p>&gt;Middle</p> <p>LEFT RIGH --- ENT</p> </div>
<p>(17) After the pile distance entry, press F4 to confirm※2)</p>	[F4]	<div data-bbox="591 1210 913 1366"> <p>Pile: 56.000</p> <p>RIGH=8.000_</p> <p>CLR ENT</p> </div>

<p>(18) It will calculate the coordinate of the setout point, press F4 to confirm.</p>	<p>[F4]</p>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">             Pile: 56.000              N: 40.000m              E: 50.000m  <div style="text-align: right;">ENT</div> </div>
<p>(19) The calculation result will display:              HR: calculated horizontal angle of the setout point,              HD: calculated horizontal distance between instrument and the setout point</p>		<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">             CACULATED  <div style="text-align: right;">HR: 123° 20' 1618"</div> <div style="text-align: right;">HD= 25.000_m</div> <div style="display: flex; justify-content: space-between; margin-top: 10px;"> <span>ANG</span> <span>DIST</span> </div> </div>
<p>(20) Press F1(ANG).              dHR: horizontal angle that should be rotated relative to the setout point= actual horizontal angle-calculated horizontal angle.              When dHR is close to 0, it means the setout direction is correct.</p>		<div style="border: 1px solid black; padding: 5px;">             PT# :  <div style="text-align: right;">HR: 123° 20' 1618"</div> <div style="text-align: right;">dHR: 123° 20' 1618"</div> <div style="display: flex; justify-content: space-between; margin-top: 10px;"> <span>DIST</span> <span>CORD</span> </div> </div>

(24) Press F4(NEXT) to enter next road point setout, the pile is automatically increased, repeat previous steps to do next pile setout.

[F4]

Road SetOut  
Pile=57.000\_



## 10. Memory Manager Mode

The following items for internal memory are available in this mode.

- 1) FILE STATUS: Checking the number of files or data in memory.
- 2) SEARCH: Searching and view point of memory.
- 3) FILE MAINTAN: Deleting files /Editing file name
- 4) COORD.INPUT: Inputting coordinate data to memory by keyboard.
- 5) DELETE COORD: Deleting coordinate data from memory.
- 6) PCODE INPUT: Inputting PCODE data into memory by keyboard.
- 7) COMM.PARAM.

SEND DATA: Sending measured data or coordinate data from instrument internal memory to other equipments.

RECEIVE DATA: Uploading measured data or coordinate data to total station internal memory.

COMM PARAMENT: Communication parameters setting

- 8) INITIALIZE: Initializing internal memory, all the file and data will be cleared.

- 9) U Function: Enter the connecting interface between ALPHA X and PC by USB port

### 10.1 Enter Memory Manager Mode

Operating procedure	Operation	Display
①Press the [MENU] key to enter menu mode.	[MENU]	<div> <div>MENU 1/2 ↓</div> <div>F1:DATA COLLECT</div> <div>F2:LAYOUT</div> <div>F3:MEMORY MGR.</div> <div>F4:PROGRAMS</div> </div>
②Press the [F3](MEMORY MGR.) key to enter memory manager mode. Press the [▲] or [▼] to turn page.	[F3]	<div> <div>MEMORY MGR. 1/3 ↓</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN</div> <div>F4:COORD INPUT</div> </div>

## 10.2 Display Internal Memory Status

Operating procedure	Operation	Display
<p>①Make sure the displaying in Memory Manager mode on page1.</p> <p>②Press the [F1] (FILE STATUS) key, the total number of stored Measured data files and Coordinate data files are shown.</p>	[F1]	<div> <p>MEMORY MGR. 1/3 ↓</p> <p>F1:FILE STATUS</p> <p>F2:SEARCH</p> <p>F3:FILE MAINTAN</p> <p>F4:COORD INPUT</p> </div> <div> <p>FILE STATUS</p> <p>MEAS. FILE : 4</p> <p>COORD. FILE : 7</p> <p>MEAS.DATA:000040</p> <p>COORDDATA:000034</p> <p>[.....]</p> </div>

## 10.3 Searching data

MEAS.DATA: Measured data.

COORD.DATA: known coordinate data for layout or station setting

PCODE Library: The data which was registered with a number from 0 to 49.

### 10.3.1 Measured data searching

Operating procedure	Operation	Display
<p>①Make sure the displaying mode in Memory Manager on page 1.</p>		<div> <p>MEMORY MGR. 1/3 ↓</p> <p>F1:FILE STATUS</p> <p>F2:SEARCH</p> <p>F3:FILE MAINTAN</p> <p>F4:COORD INPUT</p> </div>

<p>②Press the [F2] (SEARCH) key.</p> <p>③Press the [F1] (MEAS. DATA) key.</p> <p>④Press the [F1] key to input file name. Press the [F4] key to confirm.</p> <p>⑤Press the [F3](PT# DATA) key.※1)</p> <p>⑥Input PT#, press the [F4] to confirm, the point data will display in details.</p> <p>⑦Press the [F4] key to turn page, other information of this point are shown.※2) ※3)</p>	<p>[F2]</p> <p>[F1]</p> <p>[F1]</p> <p>Input file name</p> <p>[F4]</p> <p>[F3]</p> <p>Input PT#</p> <p>[F4]</p> <p>[F4]</p>	<div data-bbox="567 139 888 293"> SEARCH  F1: MEAS. DATA  F2: COORD. DATA  F3: PCODE LIB </div> <div data-bbox="567 302 888 457"> SELECT A M.FILE  FN:1    INPT LIST --- ENT </div> <div data-bbox="567 465 888 620"> MEAS. DATA SEARCH  F1: FIRST DATA  F2: LAST DATA  F3: PT# DATA </div> <div data-bbox="567 629 888 783"> PT# DATA SEARCH  PT#=_    NUM SPC CLR ENT </div> <div data-bbox="567 792 888 946"> PT#]1 1/3  N] 3713804.5836m  E] 389849.825m  Z] 959.514m ↓ </div> <div data-bbox="567 955 888 1110"> PT#]1 3/3  PCODE]  Ref.Hr] 1.680m  EDIT ↓ </div>
<p>※1) Press the [F1] key ,the first point data will be shown, press the [F2] key, the last point data will be shown.</p> <p>※2) Press the [▲ ] or [▼] key to display previous or next point data.</p> <p>※3) Press F1(EDIT) to edit the PT#, PCODE, or target height of this point.</p>		



### 10.3.2 Coordinate Data Searching

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 1.		<div>MEMORY MGR. 1/3 ↓</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN</div> <div>F4:COORD INPUT</div>
②Press the [F2] key.	[F2]	<div>SEARCH</div> <div>F1: MEAS. DATA</div> <div>F2: COORD. DATA</div> <div>F3: PCODE LIB</div>
③Press the [F2] (COORD.DATA) key.	[F2]	
④Press the [F1] key to input file name.	[F1]	<div>SELECT A C.FILE</div> <div>FN:</div> <div>INPT LIST --- ENT</div>
Press the [F4] key to confirm.	Input file name	
⑤Press the [F3] (PT# DATA) key.	[F4]	<div>COORDDATA SEARCH</div> <div>F1: FIRST DATA</div> <div>F2: LAST DATA</div> <div>F3: PT# DATA</div>
※1)	[F3]	
⑥Press the [F1] key to input PT#, press the [F4] to confirm, this point data will display	[F1]	<div>PT# DATA SEARCH</div> <div>PT#=8_</div> <div>INPT SPC CLR ENT</div>
⑦Press the [F4] key, other points information are shown.※2)	Input PT#	
	[F4]	<div>PT#]8 1/2</div> <div>N] 3725350.730m</div> <div>E] 602484.036m</div> <div>Z] 945.646m ↓</div>
※1) Press the [F1] key, the first point data will be shown, press the [F2] key, the last point data will be shown. ※2) Press the [▲] or [▼] key to display previous point data or next point data.		

### 10.3.3 PCODE Library Searching

Example searching: Number searching

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 1.		<div>MEMORY MGR. 1/3 ↓</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN</div> <div>F4:COORD INPUT</div>
②Press the [F2] key.	[F2]	<div>SEARCH</div> <div>F1: MEAS. DATA</div> <div>F2: COORD. DATA</div> <div>F3: PCODE LIB</div>
③Press the [F3] (PCODE LIB) key.	[F3]	<div>PCODEDATA SEARCH</div> <div>F1: FIRST DATA</div> <div>F2: LAST DATA</div> <div>F3: NO. SEARCH</div>
④Press the [F3]( NO. SEARCH) key.※1)	[F3]	<div>NO. SEARCH</div> <div>NO.=10_</div> <div>--- --- CLR ENT</div>
⑤Enter number. Press the [F4] key to confirm.※2)※3)	[F1] Input number [F4]	<div>&gt; 009 : SYG</div> <div>010 : AGE0</div> <div>011 : GPS</div> <div>EDIT --- CLR ---</div>

※1) Press the [F1] key ,the first point data will be shown, press the [F2] key, the last point data will be shown.

※2) Press the [▲] or [▼] key to display the previous or next PCODE, press the [F1] key to edit it, and press the [F3] key to delete this PCODE.

※3) Press [F1](Edit) to edit this PCODE.

Press [F3] (CLR) to delete this PCODE.

## 10.4 File Maintenance

In this menu, the following items are available: Renaming file name, Searching data in a file and Deleting files, special symbols will be shown.

>@AGEO_001	/C0008
*AGEO_002	/C0022
AGEO_003	/M0108
REN	SRCH
DEL	---

### (1) File discrimination mark (\*, @).

The mark (\* or @) placed ahead file name indicates the file status.

For measured data file:

“\*” means selected file for recording the measured data

For coordinate data file:

“\*” means selected file for LAYOUT mode.

“@” means selected coordinate file for DATA COLLECT mode.

### (2) Data type discrimination character (M, C)

Data type discrimination character (M, C) placed before four figures indicate the type of data.

“M” means measured data

“C” means known coordinate data

(3) Four numbers following “M” or “C” means the recorded point quantity in the file.

(4) This is a PCODE library in the memory. And it can record 50 PCODE in the library; the ID number of PCODE can be set from 01 to 50 freely.

### 10.4.1 Rename a file

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 1.		<div>MEMORY MGR. 1/3 ↓</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN</div> <div>F4:COORD INPUT</div>
②Press the [F3] (FILE MAINTAL) key, the files in memory will be shown.	[F3]	<div>&gt;*1 /M0013</div> <div>1SV /M0056</div> <div>REN SRCH DEL ---</div>
③Press the [F1] key to input the new file name, and press the F4 to confirm.	[F1] Input [F4]	<div>&gt; =AGEO_ /M0013</div> <div>1SV /M0056</div> <div>REN SRCH DEL ---</div>

### 10.4.2 Deleting a File

Operating procedure	Operation	Display
①In the files displaying mode as 10.4.1-②, Selecting a file by pressing [▼] key or [▲] key, press the [F3](DEL) key to delete.	[F3]	<div>&gt;AGEO /M0013</div> <div>1SV /M0056</div> <div>&gt;DEL? [NO] [YES]</div>
②Confirm the deleting, and press the [F4] (YES) key.	[F4]	<div>&gt;1SV /M0056</div> <div>REN SRCH DEL ---</div>

### 10.4.3 Searching Data in a File

Operating procedure	Operation	Display
①In the files displaying mode as above procedure 10.4.1-② ②Selecting a file by pressing [▼] key or [▲] key, press the [F2](SRCH) key ③Select searching method by pressing the [F1] to [F3] key.※1)	[F2]	<div>             &gt;1 /M0003              1SV /M0000              REN SRCH DEL ---           </div> <div>             &gt; 1SV /M0000                REN SRCH DEL ---           </div> <div>             SEARCH [1SV]              F1: FIRST DATA              F2: LAST DATA              F3: PT# DATA           </div>
※1) The first line displays file's name.		

### 10.5 Coordinate Data Direct Key input

Coordinate data for the layout point or control point can be input directly from keyboard. This data can be stored into a file in internal memory.

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 1. ②Press the [F4] key (COORD INPUT).	[F4]	<div>             MEMORY MGR. 1/3 ↓              F1:FILE STATUS              F2:SEARCH              F3:FILE MAINTAN              F4:COORD INPUT           </div> <div>             SELECT A C.FILE              FN:1SV                INPT LIST --- ENT           </div>

<p>③ Press the [F1] key to input File name you want to input. Press the [F4] to confirm.</p> <p>④ Press the [F1] [INPT] key to input PT#. Press the [F4] to confirm.</p> <p>⑤ Input N coordinate data, press [F4] to confirm and move to E coordinate inputting status. After input Z, enter PCODE inputting menu</p> <p>⑥ Input PCODE, press F4, “complete” will display. Then next input display is shown. Point number (PT#) can increase automatically.</p> <p>⑦ Press the [ESC] to return.</p>	<p>Input file name [F4]</p> <p>[F1] Input PT# [F4]</p> <p>[F1] Input Coord data [F4]</p>	<div data-bbox="560 138 881 293"> <p>SELECT A C.FILE FN=AGEO_  ALPH SPC CLR ENT</p> </div> <div data-bbox="560 311 881 467"> <p>COORD DATA INPUT PT#=1_  INPT LIST --- ENT</p> </div> <div data-bbox="560 485 881 641"> <p>COORD DATA INPUT N=0.000 _ m E 0.000m Z 0.000m  INPT --- --- ENT</p> </div> <div data-bbox="560 658 881 814"> <p>COORD DATA INPUT CODE:  INPT LIST ---- ENT</p> </div> <div data-bbox="560 832 881 988"> <p>COORD DATA INPUT PT#:2  INPT LIST --- ENT</p> </div>
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 10.6 Delete a Coordinate Data from a File

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 1.		<div>MEMORY MGR. 1/3 ↓</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN</div> <div>F4:COORD INPUT</div>
②Press the [▼] key to display page 2.	[▼]	<div>MEMORY MGR. 2/3 ↓</div> <div>F1:DELETE COORD</div> <div>F2:PCODE INPUT</div> <div>F3:COMM. PARAM.</div> <div>F4:INITIALIZE</div>
③Press the [F1] key. (DELETE COORD)	[F1]	
④Press the [F1] (INPT) key and enter File Name. Press the [F4] key to confirm.	[F1] INPT FILE [F4]	<div>SELECT A C.FILE</div> <div>FN:=AGEO_</div> <div>INPT LIST --- ENT</div>
⑤Press the [F1] key and enter Point Number (PT#), press [F4] key to confirm.	[F1] INPUT PT# [F4]	<div>DELETE COORD</div> <div>PT#:=15_</div> <div>INPT LIST --- ENT</div>
⑥The instrument will ask you to confirm, press [F3] to delete the selected point, or press [F4] the selected point can not be deleted.	[F3]	<div>N: 100.000 m</div> <div>E: 100.000 m</div> <div>Z: 100.000 m</div> <div>&gt;DEL? [YES] [NO]</div>

## 10.7 Editing PCODE Library

PCODE data can be entered into PCODE Library in this menu. A PCODE is linked with a number of 1 to 50. PCODE can be also edited in DATA COLLECT mode.

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 1.		<div>MEMORY MGR. 1/3 ↓</div> <div>F1:FILE STATUS</div> <div>F2:SEARCH</div> <div>F3:FILE MAINTAN</div> <div>F4:COORD INPUT</div>
②Press the [▼] key once to display page 2.	[▼]	<div>MEMORY MGR. 2/3 ↓</div> <div>F1:DELETE COORD</div> <div>F2:PCODE INPUT</div> <div>F3:COMM. PARAM.</div> <div>F4:INITIALIZE</div>
③Press the [F2] (PCODE INPUT) key.	[F2]	<div>&gt;001: 12345678</div> <div>002: SVYJMPADG</div> <div>EDIT --- CLR ---</div>
④By pressing the [▲] or [▼] keys to move the cursor.		<div>001: 12345678</div> <div>&gt;002: SVYJMPADG</div> <div>003: 1234567890</div> <div>EDIT --- CLR ---</div>
⑤Press the [F1] (EDIT) key and input PCODE at current position of cursor, press the [F4] key to confirm.	[F1] [F4]	<div>001: 12345678</div> <div>&gt;002= SVYJMPADG_</div> <div>003: 1234567890</div> <div>ALPH SPC CLR ENT</div>



## 10.8 Data Transfer by serial port

Before sending data, please connect instrument and PC correctly with RS-232C cable, and the communication settings of instrument are same as PC's settings.

The data in instrument memory can be downloading to PC, also the data can be uploaded from PC to instrument memory.

### 10.8.1 Sending data

Example: sending a measured data file.

Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 2.		<div>MEMORY MGR. 2/3 ↓</div> <div>F1:DELETE COORD</div> <div>F2:PCODE INPUT</div> <div>F3:COMM. PARAM.</div> <div>F4:INITIALIZE</div>
②Press[F3](COMM.PARA M) key.	[F3]	<div>Data Com</div> <div>F1:GTS</div> <div>F2:SSS</div>
③ Select data format. F1: GTS: Normal format F2: SSS: With code.	[F1]	
④Press the [F1] (SEND DATA) key.	[F1]	<div>Data Com.</div> <div>F1: SEND DATA</div> <div>F2: RECEIVE DATA</div> <div>F3: COMM PARAMENT</div>
Press [F1] (MEAS.DATA) key.	[F1]	<div>SEND DATA</div> <div>F1: MEAS. DATA</div> <div>F2: COORD.DATA</div> <div>F3: PCODE DATA</div>
⑤Press the [F1] key to input File Name, press the [F4] key to confirm.	[F1] Input File Data [F4]	<div>SELECT A M.FILE</div> <div>FN=AGEO_</div> <div>ALPH SPC CLR ENT</div>

<p>⑥After the receiving equipment (PC) is ready, press the [F3] (YES) to confirm, the sent point quantity will display in real-time, press F4 (STOP) to stop data sending.</p>	<p>[F3]</p>	<div data-bbox="588 138 905 293"> <p>SEND MEAS. DATA &gt;OK?</p> <p>---      ---      YES      NO</p> </div> <div data-bbox="588 330 905 486"> <p>SEND MEAS. DATA</p> <p>88</p> <p>---      ---      ---      STOP</p> </div>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## 10.8.2 Loading data

Example: Loading a coordinate data file to ALPHA X memory

Operating procedure	Operation	Display
<p>① Following steps ① to ③ of “10.8.1 Sending data”.</p> <p>②Press the [F2] (RECEIVE DATA).</p> <p>③Press [F1] (COORD.DATA) key.</p> <p>④Press the [F1] key to input File Name, press the [F4] key to confirm.</p> <p>⑤If the cable connection between ALPHA X and PC is ready, press F3(YES) to confirm.</p>	<p>[F2]</p> <p>[F1]</p> <p>[F1] Input File Data</p> <p>[F4]</p> <p>[F3]</p>	<div data-bbox="588 672 905 835"> <p>Data Com.</p> <p>F1: SEND DATA</p> <p>F2: RECEIVE DATA</p> <p>F3: COMM PARAMENT</p> </div> <div data-bbox="588 850 905 1013"> <p>LOAD DATA</p> <p>F1: COORD.DATA</p> <p>F2: PCODE LIB</p> </div> <div data-bbox="588 1028 905 1191"> <p>COORD FILE NAME</p> <p>FN=AGEO_</p> <p>ALPH   SPC   CLR   ENT</p> </div> <div data-bbox="588 1206 905 1369"> <p>LOAD COORD. DATA</p> <p>&gt;OK?</p> <p>---    ---    YES   NO</p> </div>

⑥Operate on the PC software, begin sending data from PC to ALPHA X. Press F4 (STOP) to stop data receiving.		<div> LOAD DATA  &lt;Waiting Load &gt;    ---      ---      ---      STOP </div>
----------------------------------------------------------------------------------------------------------------	--	----------------------------------------------------------------------------------------------

### 10.8.3 Setting parameter of data communications

#### Items of the Parameter

Item	Selecting item	Content
F1: Protocol	[ACK/NAK]/[NO]	Setting Protocol [ACK/NAK] or [NO] communication
F2: Baud rate	1200/2400/4800/ 9600/19200/38400	Setting transfer speed 1200/2400/4800/9600/19200 /38400 baud rate
F3: Char. / Parity	[7/EVEN]/ [7/ODD]/ [8/NON]	Setting data length and parity: [7bit, even], [7bit, odd], or [8bit, none]
F1: Stop Bits	1, 2	Setting Stop 1 bit or 2bits

## 10.9 Memory initialize

Delete all the files or clear the whole memory.

Example: Delete all the measured data files

Operating procedure	Operation	Display
<p>①Make sure the displaying is in Memory Manager mode on page 2.</p> <p>②Press [F4] (INITIALIZE) key.</p> <p>③ Select the option you can to clear.</p> <p>MEAS FILES, clear all measured files COORD FILES, clear all coordinate files PCODE FIELDS, clear all PCODEs. Format, the whole memory will be clear.</p> <p>④Press the [F3] (YES) key, all coordinate data files will be deleted. It returns to previous menu automatically.</p>	[F4]	MEMORY MGR. 2/3 ↓ F1:DELETE COORD F2:PCODE INPUT F3:COMM. PARAM. F4:INITIALIZE
		INITIALIZE F1:MEAS FILES F2:COORD FILES F3:PCODE FILES F4:Format
	[F2]	INITIALIZE Delete Coord Files? ---- -- [YES] [NO]
	[F3]	INITIALIZE F1:MEAS FILES F2:COORD FILES F3:PCODE FILES F4:Format
<b>Warning:</b> All the deleted files and data can not be restored.		

## 10.10 MEMORY SELECT

Choose to make data stored into flash memory or SD card.


Operating procedure	Operation	Display
①Make sure the displaying is in Memory Manager mode on page 3.		<div>           MEMORY MGR. 3/3 ↑            F1:MEMORY SELECT            F2:U Function            F3:DAT DATA CHANGE.         </div>
②Press F1.	[F1]	
③Press F1 to select flash memory.	[F1]	<div>           MEMORY SELECT            [F1:FLASH ]            F2:SD            ENT         </div>
④ Press F2 to select SD memory.	[F2]	<div>           MEMORY SELECT            F1:FLASH            [F2:SD ]            ENT         </div>
⑤Press F4 to confirm and it'll be back to the previous menu.	[F4]	<div>           MEMORY MGR. 3/3 ↑            F1:MEMORY SELECT            F2:U Function            F3:DAT DATA CHANGE.         </div>

## 10.11 Connect PC via miniUSB port

ALPHA X is equipped with miniUSB port, you can connect it with PC for data transferring.

Operating procedure	Operation	Display
<p>①Make sure the displaying is in Memory Manager mode on page 3.</p> <p>②Press [F2] (U Function) key.</p> <p>③Connect instrument and PC via miniUSB cable, ALPHA X will display “U FUNCTION Press ESC exit”. ※1)</p> <p>It means the ALPHA X is connected with PC already.</p> <p>Press [ESC] to disconnect them, and the instrument back to previous menu.</p>	[F2]	<p>MEMORY MGR. 3/3 ↑ F1:MEMORY SELECT F2:U Function F3:DAT DATA CHANGE.</p>
		<p>U Function Plug the USB Press ESC exit</p>
	[F2]	<p>U Function  Press ESC exit</p>
	[ESC]	<p>MEMORY MGR. 3/3 ↑ F1:MEMORY SELECT F2:U Function F3:DAT DATA CHANGE.</p>

※1) After ALPHA X is connecting with PC, the data folder in memory can be seen.



## 10.12 DAT data change


Convert measurement data or coordinate data into CASS format.

Operating procedure	Operation	Display
<p>①Make sure the displaying is in Memory Manager mode on page 3.</p> <p>②Press [F3] to select DAT DATA CHANGE.</p> <p>③Select the needed file and press F4 to confirm.</p> <p>④With it converted, it'll be back to the previous menu.</p>	[F3]	<div> <p>MEMORY MGR. 3/3 ↑  F1:MEMORY SELECT  F2:U Function  F3:DAT DATA CHANGE</p> </div>
	[F4]	<div> <p>&gt;AGEO /M0040  WS /M0040  S /M0040  ENT</p> </div>
		<div> <p>&gt;AGEO /M0040  WS /M0040  Changing ...40  ENT</p> </div>
		<div> <p>MEMORY MGR. 3/3 ↑  F1:MEMORY SELECT  F2:U Function  F3:DAT DATA CHANGE</p> </div>

## 11. Instrument Settings

In the parameters menu 1, there are some normal used settings, they are normal used for measurement.

### 11.1 Items of instrument settings





(\* factory setting)

Menu Display	Optional		Content
MIN ANG READING	1" /0.2mgon*	The min angle reading is 1" /0.2mgon	
	5" /1mgon	The min angle reading is 5" /1mgon	
	10" /2mgon	The min angle reading is 10" /2mgon	
AUTO OFF	10M/30M	After 10 or 30 minutes without any operation, power will auto-off	
	OFF *	auto-off isn't active	
TILT	OFF	The tilt sensor is OFF	
	ON *	The tilt sensor is ON	
RS-232C	BAUD RATE	1200* 2400 4800 9600 19200 38400	
	CHAR. /PARITY	7/EVEN	7 Data length, even parity
		7/ODD	7 Data length, odd parity
		8/NO NE*	8 Data length, no parity
	STOP BIT	1 *	One stop bit
		2	Two stop bit
	ACK	Stand ard	Communication way: double-action
		Omitted *	Communication way: single-action
	CR,LF	ON	With carriage return
		OFF *	Without carriage return
	REC MODE	REC-A*	Measuring and output measured data

		REC-B	Output displayed data
	Factory Set		Recall factory setting
Bright	+		Increase the reticle illumination
	-		Decrease the reticle illumination

## 11.2 Enter setting mode

Operating procedure	Operation	Display
①Make sure the displaying is menu mode on page 2.	[F2]	<div> MENU 2/2 ↑  F1: GRID FACTOR  F2:PARAMETERS1  F3:CONTRAST </div>
②Press the [F2] (PARAMETERS 1) key.		<div> PARAMETERS 1 1/2 ↓  F1: MIN ANG READING  F2: AUTO OFF  F3: TILT  F4: RS-232C </div>

# 11.3 Setting procedures

Example: change the minimum reading from 1" to 5".

Operating procedure	Operation	Display
①Make sure the displaying is on page 1 of PARAMETERS 1.		<div>PARAMETERS 1 1/2 ↓</div> <div>F1: MIN ANG READING</div> <div>F2: AUTO OFF</div> <div>F3: TILT</div> <div>F4: RS-232C</div>
②Press the [F1] key, the current setting will be shown in the“[ ]”.	[F1]	<div>MinANGLE</div> <div>[F1: 1"]</div> <div>F2: 5"</div> <div>F3: 10" ENT</div>
③Press the [F2]( 5") key, press the [F4] to confirm.	[F2] [F4]	<div>MinANGLE</div> <div>F1: 1"</div> <div>[F2: 5"]</div> <div>F3: 10" ENT</div>

## 12. Selecting Mode

### 12.1 Items of selecting mode

The following modes are available

Menu	Items	Selecting item	Display
F1: Unit	F1:Temperature	°C/°F	Select the unit of temperature for atmospheric correction
	F2:Pressure	hPa/mmHg/in Hg/psi/ mbar	Select the unit of air pressure for atmospheric correction
	F3:ANGLE	DMS(360° )/ GON(400G)/ MIL(6400M)	Choose degree, gon or mil unit for measuring angle
	F1:Dist	M/Ft/Ftin	Choose measuring unit for distance meter, feet or feet and inch
	F2:Feet	US_feet/ IN_feet	Select the meter/feet conversion factor US SURVEY feet 1m=3.280833333333333ft INTERNATIONAL feet 1m=3.280839895013123ft
F2: Mode	F1:Power On Mode	Angle/Dist	Select to set the measurement mode for angle or distance when the power is turned on
	F2:Fine/Track/Rap	Fine/Tracking /Rapid	Select Fine/Tracking/Rapid mode in distance measurement mode, when the power is turned on
	F3:HD/SD	HD&VD/SD	Specify which is displayed first, horizontal and vertical distance or slope distance, when the power is turned on

	F1:Z0/H0	VZ0/HA0	Choose the vertical angle reading from zenith or from level
F2: Mode	F1:NTIMES/ REPEAT	N TIMES/ REPEAT	Select the measurement mode for distance when the power is turned on
	F2:MEAS TIMES	0-99	Set N (number of times) for times of distance measurement. When setting number of times as 1, it is single measurement
	F3:NEZ/ENZ	NEZ/ENZ	Select a coordinate displaying order either NEZ or ENZ
	F4:Offset VA	Free /Hold	Select Vertical angle setting in the Angle Offset measurement mode. FREE: Vertical angle varies by the angle of the telescope. HOLD: Vertical angle is fixed even if the angle of the telescope changes.
	F1:ESC MODE	Collect/SO /Rec/OFF	You can select a function of the [ESC] key. DATA COLLECT/ LAYOUT: It is possible to enter data input mode (in DATA COLLECT) or Layout Menu from normal measuring mode directly. REC: While executing normal or offset measuring, the measuring data can be output. OFF: Returns to normal function

F2: Mode	F2:Coor Check	ON/OFF	Select coordinate displaying ON or OFF when setting a point
	F3:EDMOff Time	0-99	The time when EDM is cut off from distance measurement is completed can be changed. This function is effective for shortening time measuring time when distance measurement is started from distance measurement completing state. Default:3minutes) 0 :After completing distance measurement, EDM is cut off immediately. 1-99: EDM is cut off after 1~99 minutes.
	F4:Read Min	0.2mm/1mm	Select 1mm or 0.2mm for the minimum reading unit in the distance mode (FINE mode)
F3: Other	F1:HA Buzzer	ON/OFF	Specify whether the buzzer sounds or not for every horizontal angle 90°
	F2:Signal Buzzer	ON/OFF	Specify whether the buzzer sounds or not in the set audio mode.
	F3:K select	0.14/0.20/OFF	Set correction for refraction and earth curvature, efficient of refraction as ; K=0.14, K=0.20 or no correction

F3: Other	F1:Coor Rec	ON/OFF	It is possible to retain the coordinate of instrument point, the instrument height and prism height after power off.
	F1:Rec Type	REC-A/ REC-B	Select REC-A or REC-B for data output  REC-A: The measurement is made again and this new data is output.  REC-B: The data being displayed is output
	F2:CR,LF	ON/OFF	It is possible to output the data with carriage return and line feed.
	F3:NEZ Rec	Standard12/ WithMeas12	Select to record coordinates in standard or 11 digits with raw data
	F4:InputCoor Re	ON/OFF	In the layout mode or data collect mode, it is possible to record coordinates entered directly from the keyboard
	F1:ACK	Standard/Omitted	Set the procedure of the communication with external device.  STANDARD: Normal procedure  OMITTED: Even though the [ACK] is omitted from the external device, the data is sent again
	F2: GRID FACTOR	Use/Not Use	Select using GRID FACTOR in calculation of measurement data

F3: Other	F3:Staking Mode	Standard/Cut &Fill	In the layout mode, CUT & FILL can be displayed instead of dZ
	F3:Back Disp	ON/OFF	It is possible to output the data of echo back type
	F1:Contrast menu	ON/OFF	When the instrument is turned ON, it is possible to display the screen which you can adjust contrast of the display and confirm the prism constant (PSM) and atmospheric correction value (PPM)
	F2:LANGUAGE	ENGLISH/ OTHER	Select the displaying language.
	F3:Key Buzzer	ON/OFF	Setting the key pressing buzzer ON/OFF

## 12.2 How to set selecting mode

<Example>: Setting unit in °F, NEZ MEMORY:ON

Operating procedure	Operation	Display
① While pressing F2 key, turn Power ON	F2 + Power on	PARAMETERS 2 F1:UNIT F2:Mode F3:Other
②Press the [F1] key to check and set all units.	[F1]	Unit 1/2 ↓ F1: Temperature F2: Pressure F3:Angle
③Press [F1](Temperature) key, press [F2]( °F )and press[F4](ENTER) key.	[F1] [F2] [F4]	Temp. Unit [°C]  °C °F ENT



Operating procedure	Operation	Display
④ Press [ESC] key. Returns to PARAMETERS 2 menu.	[ESC]	PARAMENT 2 F1:UNIT F2:Mode F3:Other
⑤ Press [F3] (OTHER) key.	[F3]	Other 1/4 ↓ F1:HA Buzzer F2:Signal Buzzer F3:K Select F4:Coor Rec
⑥ Press [F4]( Coor Rec) key.	[F1]	Coor Rec [F1: ON ] F2: OFF ENT
⑦ Press [F1](ON) key, and press [F4] (ENTER) key. Returns to OTHERS SET menu.	[F1] [ENT]	Other 1/4 ↓ F1:HA Buzzer F2:Signal Buzzer F3:K Select F4:Coor Rec
⑧ Power off		

## 13. Check and adjustment


### 13.1 Checking and adjusting of instrument constant

Instrument constant means additive constant for distance measurement. Normally, the instrument constant doesn't have error. It is recommended you measure and compare with an accurately measured baseline one consistent ground. If such a baseline is not available, establish your own base line over 20m and compare the data measured with the newly purchased instrument.

In case, the instrument setup, the prism, baseline precision, poor collimation, atmospheric correction, correction for refraction and earth curvature determine the inspection precision.

Also, when providing a base line indoor, the following procedure as shown below could be used to check the instrument constant.

(1) Provide point B on a straight line AC, which is almost level and about 100m long. Measure straight lines AB, AC and BC.



(2) Obtain the instrument constant by repeat measurement,

$$\text{Instrument constant} = AB + BC - AC$$

(3) When there is error between written instrument constant value and calculated value, only need to synthesize the instrument constant and prism constant, and then input the synthesized data in prism constant form, please refer to "7.3.1 Setting of the prism constant".

(4) Once again, measure at a calibrated baseline and compare results.

(5) If using above procedure a difference of over 5mm is found, the instrument constant need reset as the operating procedure on next page.

Operating procedure	Operation	Display
① Press the [F1] key and power [①] key at the same time to enter service menu.	[F1]+ [①]	PASSWORD  INPT --- ENT
② Press the [F1] key, and input the password 1120, press the [F4] key to confirm.	[F1] [1120] [F4]	ADJUSTMENT MODE F1: V INDEX ADJ. F2: INST. CONST F3: SET DEFAULT!!
③ Press the [F2] key.	[F2]	INST. CONST SET CONST: 000mm  INPT --- ENT
④ Press the [F1] key.	[F1]	INST. CONST SET CONST: 0002_ mm  --- CLR ENT
⑤ Press the [F1] key to input new constant, press the [F4] to confirm.	[F1] input constant [F4]	INST. CONST SET CONST:0008 mm SET? --- YES NO
⑥ Press the [F3] (YES) key. Press any key, the instrument finish setting and power off automatically. ※1)	[F3] Any key	INST. CONST SET CONST:0008 mm SET? Waiting... [NO]  Save Ok!
※1) Press the [F4](NO) key to cancel the setting.		

## 13.2 Checking/adjusting the plate level

(1) Set the instrument on stable device (such as tripod or adjusting table) and fix it.

(2) Level the instrument roughly, place the plate level parallel to a join-line of two leveling screws, say, A and B. Use these two leveling screws only and place the bubble in the center of the plate level.

(3) Rotate the instrument  $180^\circ$  and check bubble movement of the plate level. If the bubble has always been in the center of the plate level, then it is not needed to adjust. If the bubble has been displaced (deviate the center away half of one grid), then adjust it.

### Adjustment


(1) Set the instrument on stable device and fix it.

(2) Level the instrument roughly.

(3) Place the plate level parallel to a join-line of two leveling screws. Use these two leveling screws only and place the bubble in the center of the plate level.

(4) Rotate the instrument  $180^\circ$ . When the bubble stable, adjust the level adjustment screw with the adjusting pin and return the bubble towards the center of the plate level. Correct only one-half of the displacement by this method.

(5) Repeat the procedures of (3) and (4) until anywhere the instrument moves to, the bubble will always be in the center of the plate level.




### 13.3 Checking/adjusting the circular level Check

- (1) Set the instrument on stable device and fix it;
- (2) Precisely level the instrument with the plate level;
- (3) Look the bubble of the circular level whether is in the center; if the bubble is centered properly, adjustment is not required. Otherwise, adjust it.

#### Adjustment

- (1) Set the instrument on stable device and fix it;
- (2) Precisely level the instrument with the plate level;
- (3) Shift the bubble to the center of the circular level, by adjusting two adjustment screws with the adjusting pin.


**NOTE:** When adjust with pin, you should do that with smaller strength, the loose-tight degree of two screws should be similar.



## 13.4 Checking/adjusting the optical sight


### Check

- (1) Set the instrument on stable device and fix it;
- (2) Set a cross mark front the instrument 50m apart;
- (3) Let the telescope collimate the cross mark;
- (4) Observe the optional sight collimator whether collimating the cross mark, if collimates the mark, adjusting is not required. Otherwise, adjust it.



### Adjustment

- (1) Set the instrument on stable device and fix it;
- (2) Set a cross mark front the instrument 50m apart;
- (3) Let the telescope collimate the cross mark;
- (4) Loose two fixed screws of optional sight and adjust them, when the optional sight on proper place fix the two fixed screws.



## 13.5 Checking/Adjusting the plummet


### 13.5.1 Checking/Adjusting the optical plummet Check

(1) Set the instrument on stable device and fix it.

(2) Set a cross mark under the instrument.

(3) Use the three leveling screws and coincide the center mark of plummet and cross mark on the ground.

(4) Rotate the instrument  $180^\circ$  around and check the center mark and cross mark, if they are coincide, adjustment is not required. Otherwise, adjust it.



#### Adjustment

(1) Set the instrument on stable device and fix it.

(2) Set a cross mark under the instrument.

(3) Use the three leveling screws and coincide the center mark of plummet and cross mark on the ground.

(4) Rotate the instrument  $180^\circ$  around and take off the cover of the optical plummet eyepiece, adjust the four adjusting screws with the adjusting pin to shift the center mark to the cross mark, correct only one-half of the displacement in this manner.

(5) Repeat the operation in (3) and (4) until coincide the center mark of the plummet and cross mark on the ground.

### 13.5.2 Checking/Adjusting the laser plummet (Optional accessory) Check

- (1) Set the instrument on stable device and fixes it;
- (2) Set a cross mark on the ground under the instrument;
- (3) Turn the three leveling screws until the instrument keeps leveling and the laser spot coincides with the cross mark on the ground;
- (4) Rotate the instrument  $180^{\circ}$ (200g) around and check the laser spot and cross mark, if they are coincide, adjustment is not required. Otherwise, adjust it.

#### Adjustment

- (1) Set the instrument on stable device and fixes it;
- (2) Set a cross mark on the ground under the instrument;
- (3) Turn the three leveling screws until the instrument keeps leveling and the laser spot coincides with the cross mark on the ground;
- (4) Rotate the instrument  $180^{\circ}$ (200g) around and take off the protecting cover of the laser plummet, adjust the four adjusting screws with the screwdriver to move the laser spot to the cross mark, correct only one-half of the displacement in this manner.
- (5) Repeat the operation in (3) and (4) until the instrument keeps leveling and the laser spot coincides with the cross mark when rotating alidade of instrument to any direction.





### 13.6 Checking/Adjusting the vertical cross-hair on telescope

(1) Set the instrument up on the tripod and carefully level it.

(2) Set a point A front the instrument 50m apart;

(3) Collimate the point A and adjust the vertical tangent screw; if the point appears to move

continuously on the hair, adjustment is not required. Otherwise, adjust it.




#### Adjustment

(1) Set the instrument, and set the point A front the instrument 50m apart.

(2) Take off cover of telescope eyepiece, rotate the vertical tangent screw and loosen all four adjusting screws slightly with the cross screw-drive, then revolve the eyepiece section so that the vertical cross-hair coincide to point A, finally, re-tighten the four screws.

(3) Repeat the operation in check (3) and adjusting (2) until there is no deviation.



### 13.7 Checking/adjusting horizontal collimation error Check

- (1) Set-up the instrument on tripod or adjustment platform and leveling accurately;
- (2) Aim at the cross-hairs of collimator or the obvious target at a distance. Get the face left angle reading  $H_l$  and the face right angle reading  $H_r$ .
- (3) Calculating the horizontal collimation error  $C$  according to  $C = (H_l - H_r \pm 180^\circ) / 2$  if  $C < 8''$ , no adjustment will be necessary. If  $C > 8''$ , proceed with the following adjustment.

#### Adjustment

- (1) Rotate the instrument in face right position, turning horizontal tangent screw until  $H_r' = H_r + C$ .
- (2) Loosen the shield of telescope's reticule adjusting two screws at left and at right until the vertical hairs of telescope's reticule coincides with the cross-hairs of collimator or target.
- (3) Repeat the check and adjustment procedure until it is up to standard.

### 13.8 Checking/adjusting of the vertical index error i.

Finish the adjustment of the across-hair and the error  $2C$ , and then begin this adjustment.

Finish the adjustment of the across-hair and the error  $2C$ , and then begin this adjustment.

#### Check

- (1) Set-up the instrument on tripod or adjustment platform and leveling accurately.
- (2) Aim at the cross-hairs of collimator or the obvious target at a distance, which should be about  $\pm 10^\circ$  away from the horizon. Read the face left angle reading  $V_l$  and the face right angle reading  $V_r$ .
- (3) Calculating the vertical index error  $i = (V_l + V_r - 360^\circ) / 2$ .
- (4) If  $i < 10''$ , adjustment is not required. Otherwise, adjust it.

## Adjustment

If the vertical index I is too bigger, using program to adjust.

Operating procedure	Operation	Display
① Press the [F1] key and [①] power key at same time. ※1)	[F1]+[①]	PASSWORD:  INPT --- ENT
② Press the [F1] key to input the password 1120, press [F4] key to confirm.	[F1] [1120] [F4]	ADJUSTMENT MODE F1: V INDEX ADJ. F2: INST. CONST F3: SET DEFAULT!!
③ Press the [F1] key.	[F1]	V INDEX ADJ. <STEP-1> FACE 1 VZ: 95° 22' 04" ENT
④ Rotate the telescope about one circle.	Initializa tion	V INDEX ADJ. <STEP-2> FACE 2 VZ: 275° 40' 04" ENT
⑤ At face-left collimate the reticule of collimator, press the [F4] key to confirm. ※2)※3)	[F4] collimate (Left)	V INDEX ADJ. Vl: -5° 22' 04" SET? YES NO
⑥ At face-right collimates the reticule of collimator, press the [F4] key to confirm.	[F4] collimate (Right)	V INDEX ADJ. Vl: -5° 22' 04" SET? Waiting...

<p>⑦Press the [F4] key to confirm.</p> <p>⑧Press the [F3](YES) key.※4)</p> <p>⑨Press any key, the instrument finish the setting and power off automatically.</p>	<p>[F4]</p> <p>[F3]</p> <p>Any key</p>	<div data-bbox="614 139 932 295" style="border: 1px solid black; padding: 5px;"> V INDEX ADJ.  VI: -5° 22' 04"  SET?  Save OK! </div>
<p>※1) Before adjusting the error, set the instrument on tripod or adjustment platform and fix it with column screw, leveling it accurately and open the compensator.</p> <p>※2) The collimator or target will not apart away from horizontal line <math>\pm 10^\circ</math></p> <p>※3) Collimate the target at normal position firstly, and then collimate the target at reverse position, users must operate the instrument according to the displaying information.</p> <p>※4) Press the [F3] key to cancel the setting, and power off automatically.</p>		

### 13.9 Checking the optical axis

Finish the adjustment of the cross-hairs and the error 2C, then check the coincide of the sight-axis and EDM-axis.

#### Check

- (1) Set-up a prism at a distance, which should be about 100m away from the instrument.
- (2) Set-up the instrument on tripod or adjustment platform and leveling accurately, then switch on.
- (3) Collimate the center of the prism, measure distance in the way which be introduced in chapter 7.
- (4) If the receiving is well, the buzzer will sound immediately and the measuring result will display in short time, then the adjustment is not requirement.

#### Adjustment

If the case is different with introduction in (4), please contact with our local dealer.

This check should be do in fine atmospheric conditions

## 14. Packing list

●Carrying case	1each
●Instrument	1each
●Battery	2 each
●Charger	1 each
●Tool kit	1each
●Instruction manual	1each
●Disc	1 each
●Communication cable	1 each
●Reflective sheet	2 each

## **Attachment 1: atmospheric correction formula and chart (for your reference)**

Factory setting: temperature: 20°C, pressure:1013hPa, 0ppm

The correction:

$$K_{pt} = 274.417 - 0.2905 * p / (1 + 0.0036 * t)$$

$$K_{pt} = 278.960 - 0.2904 * p / (1 + 0.0036 * t)$$

Where: p--Pressure value (hPa)

t--Temperature value ( °C)

Kpt--Atmospheric correction (ppm)

Example:


t=15°C, p=1013hpa, L0=1000m.

Then: Kpt=0ppm


$$L = L_0(1 + K_{pt}) = 1000 \times (1 + 0 \times 10^{-6}) = 1000.000m$$

The atmospheric value is obtained easily with the atmospheric correction chart. Find the measured temperature in horizontal axis, and pressure in vertical axis on the chart.

Read the value from the diagonal line, which is the required atmospheric correction value.







## Attachment 2 Correction for refraction and earth curvature

Horizontal distance and vertical distance calculation formula: with correction for refraction and earth curvature taken into account:

Horizontal distance:  $D=AC$  ( $\alpha$ ) or  $BE$  ( $\beta$ )

Vertical distance:  $Z=BC$  ( $\alpha$ ) or  $EA$  ( $\beta$ )

$$D=L\{\cos\alpha - (2\theta - \gamma)\sin\alpha\}$$

$$Z=L\{\sin\alpha + (\theta - \gamma)\cos\alpha\}$$


$\theta = L \cdot \cos\alpha / 2R$  .....Earth curvature correcting item

$\gamma = K \cdot L \cos\alpha / 2R$  .....Atmospheric refraction correcting item

$K=0.14$  or  $0.20$  .....Coefficient of refraction

$R=6372\text{km}$  .....Radius of earth

$\alpha$  (or  $\beta$ ) .....Altitude angle       $L$  .....Slope distance



The conversion formula for horizontal and vertical distance is as follows when correction for refraction and earth curvature is not applied:

$$HD=L \cos\alpha$$

$$VD=L \sin\alpha$$

## **Attached file 3: communication instruction and data format**

### 1) Communication parameters setting

BAUD RATE (Baud rate): 2400/4800/9600/19200/38400

PARITY (Parity mode)NONE/ODD/EVEN

DATA BITS (Data length): 7/8

STOP BITS (Stop bit): 0/1/2

PROTOCOL(Protocol): XON/XOFF, NONE

### 2) Data format

#### **Uploading coordinate data format**

| C1 | C2 | C3 | ... | Cn | CR | LF |

C1-Cn:

PT#,X,Y,Z,PCODE

NOTE: there is no blank after comma

Example:

101,994.815,1000,987,100.113,STN

CR(ODH) and LF(OAH) at the ending of data block, means the ending mark of data block

#### **Downloading data format:**

CONTROL WORD field1.....fieldn

CONTROL WORD, with blank to finish

field1 to fieldn-1 with comma to finish

fieldn with CR(ODH) and LF(OAH) to finish

Control code and attached information:

JOB Job name, description  
 NAME Surveyor name  
 INST Description of instrument model  
 UNITS meter/feet, degree/gon  
 SCALE Grid factor, scale factor, elevation  
 ATMOS Temperature, pressure  
 STN PT#, instrument height, PCODE  
 XYZ X (N coordinate), Y(E coordinate), Z(elevation)  
 BKB PT#, azimuth of backsight point, angle of backsight point  
 BS PT#[. target height]  
 FS PT# target height, PCODE[ , serial code]  
 SS PT# target height, PCODE[ , serial code]  
 CTL control code[, point code 2[ , serial code2](Select one optionally)  
 HV HA (Horizontal angle), VA( vertical angle)  
 SD HA (Horizontal angle), VA(Vertical angle), SD(Slope distance)  
 HD HA (Horizontal angle), HD(Horizontal distance), VD(height difference)  
 OFFSET Radial offset, tangent offset, vertical offset  
 PTL\_OFF offset on the reference line direction, offset on the line  
 which is cross at right angles with reference line  
 NOTE Note content

**NOTE:**

These designs, figures and specifications are subject to change without notice. We shall not be held liable for damages resulting from errors in this instruction manual.



**GUANGZHOU ALPHA GEO-INFO CO.LTD**

[Https://alphageo-info.com](https://alphageo-info.com)

Mail:alphageo@aliyun.com

Address: Building No.1,  
Gaopu Road No.68,Tianhe District,  
Guangzhou510630,Guangdong,China

